



WIPER AND WASHER SYSTEM PARTS LOCATION

DEOKN-01



TROUBLESHOOTING

The table below will be useful for you in troubleshooting these electrical problems. The most likely causes of the malfunction are shown in the order of their probability. Inspect each part in the order shown, and replace the part when it is found to be faulty.

Trouble	Parts name	(See page) (Front) (Rear)
Wiper do not operate or return to off position.	1. WIPER Fuse 2. Wiper Switch 3. Wiper Motor 4. Wiper Relay 5. Wire Harness	(BE-4) (BE-4) (BE-36) (BE-36) (BE-38) (BE-39) (BE-37) (BE-38)
Wiper do not operate in MIST.	1. Wiper Switch 2. Wiper Motor 3. Wiper Relay 4. Wire Harness	(BE-36) (BE-36) (BE-38) (BE-39) (BE-37) (BE-38)
Wiper do not operate in INT.	1. Wiper Switch 2. Wiper Motor 3. Wiper Relay 4. Wire Harness	(BE-36) (BE-36) (BE-38) (BE-39) (BE-37) (BE-38)
Washer does not operate.	1. Washer Hose or Nozzle Clogged 2. Washer Switch 3. Washer Motor 4. Wire Harness	(BE-36) (BE-40) (BE-40)

COMBINATION SWITCH REMOVAL

REMOVE FRONT WIPER AND WASHER SWITCH

See page [BO-61](#).

COMBINATION SWITCH INSTALLATION

INSTALL FRONT WIPER AND WASHER SWITCH

See page [BO-61](#).

COMBINATION SWITCH INSPECTION

INSPECT FRONT WIPER AND WASHER SWITCH

Continuity


Switch position	Tester connection to terminal number	Specified value
Wiper OFF	B4-B7 (L-R) - (L-B)	Continuity
Wiper INT	B4 - B7 (L - R) - (L - B)	Continuity
Wiper LO	B7-B18 (L-B) - (L-W)	Continuity
Wiper HI	B13 - B18 (L-0) - (L-W)	Continuity
Washer OFF	-	No continuity
Washer ON	B8-B16 (L) - (B)	Continuity

INSPECT REAR WIPER AND WASHER SWITCH



Continuity

Switch position	Tester connection to terminal number	Specified value
Washer ON	B2 B16 (v) - (6)	Continuity
Wiper OFF	-	No continuity
Wiper INT	B10 - 816 (0) - (B)	Continuity
Wiper ON	B1 - B16 (G) - (B)	Continuity
Washer ON	B1 B2 B16 (G) - (V) - (B)	Continuity

If continuity is not as specified, replace the switch.



BE0930-01




FRONT WIPER RELAY INSPECTION

INSPECT FRONT WIPER RELAY

Operation at Intermittent

- Turn the wiper switch to INT position.
 - Turn the intermittent time control switch to FAST position.
 - Connect the positive (+) lead from the battery to terminal 1318 and the negative (-) lead to terminal B 16.
 - Connect the positive (+) lead from the voltmeter to terminal B7 and the negative (-) lead to terminal B1 6, check that the meter needle indicates battery positive voltage.
 - After connecting terminal B4 to terminal B18, connect to terminal B 16.
- Then, check that the voltage rises from 0 volt to battery positive voltage within the times, as shown in the table.





V02744

If operation is not as specified, replace the switch.

Operation as Washer Linked


- Connect the positive (+) lead from the battery to terminal B18 and the negative (-) lead to terminal B 16.
- Connect the positive (+) lead from the voltmeter to terminal B7 and the negative (-) lead to terminal B16.
- Push in the washer switch. Check that the voltage changes, as shown in the table.



If operation is not as specified, replace the switch.

V02745

Relay Side



H-6-2

Z06843

REAR WIPER RELAY INSPECTION

INSPECT REAR WIPER RELAY

Continuity

- Check that there is no continuity between terminals 1 and 3.
- Check that there is continuity between terminals 2 and 3.


If continuity is not as specified, replace the relay.

Operation

- Connect the positive (+) lead from the battery to terminal 1 and the negative (-) lead to terminal 6.
- Connect the positive (+) lead from the voltmeter to terminal 2 and the negative (-) lead to terminal 6, check that the meter needle indicates 0 volts.
- Connect the positive (+) lead from the voltmeter to terminal 3 and the negative (-) lead to terminal 6, check that the meter needle indicates battery positive voltage.

If operation is not as specified, replace the relay.


Battery positive voltage



BE1687

Z09699

Within 6 to 10 seconds



BE1702

Intermittent Operation

- Connect the positive (+) lead from the battery to terminal 2 and the negative (-) lead to terminal 4.
- Connect the positive (+) lead from the voltmeter to terminal 3 and the negative (-) lead to terminal 4.
- After disconnecting the positive (+) lead from terminal 2, connect it to terminal 1, and then, check that the meter needle rises from 0 volts to battery positive voltage within 6 to 10 seconds.

If operation is not as specified, replace the relay.


FRONT WIPER MOTOR INSPECTION

INSPECT FRONT WIPER MOTOR


Operation at Low Speed

Connect the positive (+) lead from the battery to terminal 3 and negative (-) lead to terminal 1 check that the motor operates at low speed.

If operation is not as specified, replace the motor.




N06188




Operation at High Speed

Connect the positive (+) lead from the battery to terminal 2 and the negative (-) lead to terminal 1. check that the motor operates at high speed. If operation is not as specified, replace the motor.




Operation, Stopping at Stop Position

(a) Operate the motor at low speed and stop the motor operation anywhere except at the stop position by disconnecting positive (+) lead from terminal 3.



(b) Connect terminal 3 and 5.

(c) Connect the positive (+) lead from the battery to terminal 6 and the negative (-) lead to terminal 1, check that the motor stops running at the stop position after the motor operates again. If operation is not as specified, replace the motor.




REAR WIPER MOTOR INSPECTION

BE0L0-01

INSPECT REAR WIPER MOTOR


Operation at Low Speed

Connect the positive (+) lead from the battery to terminal 3 and negative (-) lead to terminal 2, check that the motor operates at low speed. If operation is not at specified, replace the motor.



Operation. Stopping at Stop Position


(a) Operate the motor at low speed and stop the motor operation anywhere except at the stop position by disconnecting positive (+) lead from terminal 3.



(b) Connect terminal 3 and 4.

(c) Connect the positive (+) lead from the battery to terminal 1 and the negative (-) lead to terminal 2, check that the motor stops running at the stop position after the motor operates again.

If operation is not as specified, replace the motor.



WASHER MOTOR INSPECTION

INSPECT WASHER MOTOR

Front:

Connect the positive (+) lead from the battery to terminal 2 and the negative (-) lead to terminal 1, check that the motor operates.

NOTICE: These tests must be performed quickly (within 20 seconds) to prevent the coil from burning out.

If operation is not as specified, replace the motor.

Rear:

Connect the positive (+) lead from the battery to terminal 1 and the negative (-) lead to terminal 2, check that the motor operates.

NOTICE: These tests must be performed quickly (within 20 seconds) to prevent the coil from burning out.

If operation is not as specified, replace the motor.

