

Use the table below to help you find the cause of the problem. The numbers indicate the priority of the likely cause of the problem. Check each part in order. If necessary, replace these parts.

See page	Part Name (Trouble)	Low pedal or spongy pedal	Brake drag	Brake pull	Hard pedal but brake inefficient	Noise from brakes
-	Brake system (Fluid leaks)	1			1	
-	Brake system (Air in)	2			2	
BR-20, 27, 39	Brake pad or lining (Worn)				3	
BR-20, 27	Piston seal (Worn or damaged)	3				
BR-7	Brake pedal (Freeplay minimal)		1			
BR-11	Master cylinder (Faulty)	5	11			
BR-27, 39	Rear brake (Shoe clearance out of adjustment)	4	4		5	
BR-10	Parking brake (Lever travel out of adjustment)	2				
-	Parking brake wire (Sticking)	3				
BR-19	Booster push rod (Out of adjustment)	6	9		9	
BR-27	Anchor or return spring (Faulty)	8	8			8
BR-20, 27, 39	Pad or lining (Cracked or distorted)		5	5	4	1
BR-20, 27, 39	Piston (Stuck)		6	1		
BR-24, 27, 39	Pad or lining (Oily)			2	6	
BR-20, 27, 39	Piston (Frozen)		7	3		
BR-8	Booster system (Vacuum leaks)		10		10	
BR-20, 39	Pad support plate (Loose)					4
BR-20, 27, 39	Installation bolt (Loose)					2
BR-20, 39	Sliding pin (Worn)					5
BR-20, 39	Disc (Scored)			4	8	3
BR-20, 27, 39	Pad or lining (Dirty)					6
BR-20, 27, 39	Pad or lining (Hardened)				7	7
BR-20, 39	Anti-squeal shim (Damaged)					9
BR-27	Hold-down spring (Damaged)					10