


CHARGING



SERVICE HINTS

G 1(A) GENERATOR (ALTERNATOR)

- (A) 1-GROUND: 13.9-15.1 VOLTS WITH ENGINE RUNNING AT 2000 RPM AND 25°C (77°F)
13.5-14.3 VOLTS WITH ENGINE RUNNING AT 2000 RPM AND 115°C (239°F)
(A) 2-GROUND: 0-4 VOLTS WITH IGNITION SW AT **ON** POSITION AND ENGINE NOT RUNNING

○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
C11	B 23	F10	A 22	G 2	B 22
C12	A 23	F13	23		
F 8	B 22	G 1	A 22		

○ : RELAY BLOCKS




CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	18	R/B NO. 2 (FRONT SIDE OF LEFT FENDER)

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
EA1	26	COWL WIRE AND ENGINE ROOM MAIN WIRE (LEFT FENDER)

○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
I12	28	COWL WIRE			



F13
(SEE PAGE 20)

