





- *1: All accessories and A/C are switch OFF.
- *2: Station wagon only.
- *3: Hardtop only.
- *4: If the engine coolant temperature sensor circuit is open or shorted, the engine ECU assumes an engine coolant temp. value of 80°C (176°F).
- *5: Europe only.
- *6: When feedback control is forbidden, 0 V is displayed.
- *7: A/T only.

AIR FLOW METER (Station Wagon) COMPONENTS FOR REMOVAL AND INSTALLATION

EG54N-02





AIR FLOW METER REMOVAL

Installation is in the reverse order of removal.

1. REMOVE AIR CLEANER CAP AND AIR FLOW METER

- Disconnect the air flow meter connector and wire clamp.
- Disconnect the cruise control actuator cable.
- Loosen the air cleaner hose clamp.
- Disconnect the 3 clips, and remove the wing nut, air cleaner cap and air flow meter.

2. REMOVE AIR FLOW METER

Remove the 4 bolts, bracket and air flow meter.

Torque: 6.9 N·m (70 kgf·cm, 61 in.-lbf)


AIR FLOW METER INSPECTION

1. INSPECT AIR FLOW METER RESISTANCE

Using an ohmmeter, measure the resistance between terminals THA and E2.

Between terminals	Resistance	Temperature
THA — E2	10 — 20 k Ω	−20°C (−4°F)
THA — E2	4 — 7 k Ω	0°C (32°F)
THA — E2	2 — 3 k Ω	20°C (68°F)
THA — E2	0.9 — 1.3 k Ω	40°C (104°F)
THA — E2	0.4 — 0.7 k Ω	60°C (140°F)
THA — E2	0.2 — 0.4 k Ω	80°C (176°F)

If the resistance is not as specified, replace the air flow meter.



2. INSPECT AIR FLOW METER OPERATION

- Connect the air flow meter connector.
- Using a voltmeter, connect the positive (+) tester probe to terminal VG, and negative (−) tester probe to terminal E3.
- Blow air into the air flow meter, and check that the voltage fluctuates.
If operation is not as specified, replace the air flow meter.
- Disconnect the air flow meter connector.