




AIR CONDITIONING CONTROL ASSEMBLY



A/C CONTROL ASSEMBLY REMOVAL

Installation is in the reverse order of removal.

1. **REMOVE INSTRUMENT CLUSTER FINISH CENTER PANEL WITH A/C CONTROL ASSEMBLY**
2. **REMOVE A/C CONTROL ASSEMBLY**

Remove the 3 screws and A/C control assembly from center panel.


A/C CONTROL ASSEMBLY INSPECTION



1. INSPECT ILLUMINATION OPERATION

Connect the positive (+) lead from the battery to terminal A-13 and the negative (-) lead to terminal A-3, then check that the illuminations light up.


If illuminations do not light up, test the bulb.




2. INSPECT INDICATOR LIGHT OPERATION

Air Inlet Control Switch:

- Connect the positive (+) lead from the battery to terminal A-9 and the negative (-) lead to terminal A-8.
- With the air inlet control button pushed in, check that the FRESH or RECIRC indicator light lights up.
- Next, push in the button again, and check that the indicator light goes off and the other indicator light lights up.




- Then connect the positive (+) lead from the battery to terminal A-13 and check that the indicator dims. If operation is not as specified, replace the A/C control assembly.




Mode Control Switch:

- Connect the positive (+) lead from the battery to terminal A-9 and the negative (-) lead to terminal B-16.
- Push each of the mode buttons in and check that their indicator light lights up.




- Then connect the positive (+) lead from the battery to terminal A-13 and check that the indicator dims. If operation is not as specified, replace the A/C control assembly.




Blower Speed Control Switch:

- Connect the positive (+) lead from the battery to terminal A-9 and the negative (-) lead to terminal B-16.
- Push each of the blower speed control buttons in and check that their indicator light lights up.




- (c) Then connect the positive (+) lead from the battery to terminal A-13 and check that the indicator dims. If operation is not as specified, replace the A/C control assembly.




A/C Switch:

- (a) Connect the positive (+) lead from the battery to terminal A-9 and the negative (-) lead to terminal B-18.
- (b) Push the A/C switch button in and check that the indicator light lights up.



- (c) Then, connect the positive (+) lead from the battery to terminal A-13 and check that the indicator dims. If operation is not as specified, replace the A/C control assembly.


3. INSPECT AIR INLET CONTROL SWITCH CONTINUITY



V02045

If continuity is not as specified, replace the A/C control assembly.


4. INSPECT MODE CONTROL SWITCH CONTINUITY



Switch position	Tester connection to terminal number	Specified condition
FACE	A14 – B16	Continuity
BI-LEVEL	A12 – B16	Continuity
FOOT	A17 – B16	Continuity
FOOT-DEF	B11 – B16	Continuity
DEF	B4 – B16	Continuity

If continuity is not as specified, replace the A/C control assembly.


5. INSPECT BLOWER SPEED CONTROL SWITCH CONTINUITY



V02047

If continuity is not as specified, replace the A/C control assembly.

Connector "B"




e-18-2-B

N06436

6. INSPECT A/C SWITCH CONTINUITY

Check that there is continuity between terminals B-6 and B-17 intermittently each time the A/C switch button pressed. If continuity is not as specified, replace the A/C control assembly.

Connector "B"



e-18-2-B

N06436

TEMPERATURE CONTROL SWITCH INSPECTION**INSPECT TEMPERATURE CONTROL SWITCH RESISTANCE**

- (a) Measure the resistance between terminals B-1 and B-2.

Standard resistance:

Approx. 3.0 kΩ

- (b) Check that the resistance between terminals B-1 and B-3 increases from 0 to approx. 3.0 kΩ when the switch knob is turned from COOL to HOT.

If operation is not as specified, replace the A/C control assembly.

A/C CONTROL CABLES ADJUSTMENT**ADJUST WATER VALVE CONTROL CABLE**

(See page [AC-46](#))