




POWER WINDOW SYSTEM PARTS LOCATION



TROUBLESHOOTING

The table below will be useful for you in troubleshooting these electrical problems. The most likely causes of the malfunction are shown in the order of their probability. Inspect each part in the order shown, and replace the part when it is found to be faulty.

Trouble	Parts name	(See page)
Power window does not operate.	1. GAUGE Fuse	(BE-5)
	2. POWER Fuse	(BE-5)
	3. Power Main Relay	(BE-59)
	4. Wire Harness	
"One Touch Power Window System" does not operate.	1. Power Window Master Switch	(BE-53)
Only one window does not operate.	1. Power Window Switch	(BE-56)
	2. Power Window Motor	(BE-57)
	3. Wire Harness	



BE2594

S-14-2B

Z06846

POWER WINDOW MASTER SWITCH INSPECTION

1. INSPECT SWITCH CONTINUITY

Front Driver's Switch (Window unlock)

Switch position	Tester connection to terminal number	Specified condition
UP	1 or 2 – 13 6 – 7 or 8	Continuity
OFF	1 or 2 – 6 – 13	Continuity
DOWN	1 or 2 – 6 7 or 8 – 13	Continuity

Front Driver's Switch (Window lock)

Switch position	Tester connection to terminal number	Specified condition
UP	1 or 2 – 13 6 – 7 or 8	Continuity
OFF	1 or 2 – 6 – 13	Continuity
DOWN	1 or 2 – 6 7 or 8 – 13	Continuity

Front Passenger's Switch (Window unlock)

Switch position	Tester connection to terminal number	Specified condition
UP	1 or 2 – 5 7 or 8 – 12	Continuity
OFF	1 or 2 – 5 – 12	Continuity
DOWN	1 or 2 – 12 5 – 7 or 8	Continuity

Front Passenger's Switch (Window lock)

Switch position	Tester connection to terminal number	Specified condition
UP	7 or 8 – 12	Continuity
OFF	5 – 12	Continuity
DOWN	5 – 7 or 8	Continuity

Rear Left Switch (Window unlock)

Switch position	Tester connection to terminal number	Specified condition
UP	1 or 2 – 9 7 or 8 – 10	Continuity
OFF	1 or 2 – 9 – 10	Continuity
DOWN	1 or 2 – 10 7 or 8 – 9	Continuity

Rear Left Switch (Window lock)

Switch position	Tester connection to terminal number	Specified condition
UP	7 or 8 – 10	Continuity
OFF	9 – 10	Continuity
DOWN	7 or 8 – 9	Continuity


Rear Right Switch (Window unlock)

Switch position	Tester connection to terminal number	Specified condition
UP	1 or 2 – 14 7 or 8 – 11	Continuity
OFF	1 or 2 – 11 – 14	Continuity
DOWN	1 or 2 – 11 7 or 8 – 14	Continuity


Rear Right Switch (Window lock)

Switch position	Tester connection to terminal number	Specified condition
UP	7 or 8 - 11	Continuity
OFF	11 - 14	Continuity
DOWN	7 or 8 - 14	Continuity

If continuity is not as specified, replace the master switch.


**2. INSPECT SWITCH ILLUMINATION**

- Set the window lock switch to the unlock position.
- Connect the positive (+) lead from the battery to terminal 7 and the negative (-) lead to terminal 1, and check that all the illuminations light up.



- Set the window lock switch to the lock position, and check that all the passenger's power window switch illuminations go out.


If operation is not as specified, replace the master switch.


**3. INSPECT ONE TOUCH POWER WINDOW SYSTEM USING AN AMMETER:**

- Disconnect the connector from the master switch.
- Connect the positive (+) lead from the ammeter to terminal 6 on the wire harness side connector and the negative (-) lead to negative terminal of the battery.
- Connect the positive (+) lead from the battery to terminal 13 on the wire harness side connector.
- As the window goes down, check that the current flow is up to approximately 7 A.
- Check that the current increases approximately 14.5 A or more when the window stops going down.

HINT: The circuit breaker opens some 4-40 seconds after the window stops going down, so that check must be made before the circuit breaker operates.


If the operation is as specified, replace the master switch.






USING AN AMMETER WITH A CURRENT-MEASURING PROBE:

- (a) Remove the master switch with connector connected.
- (b) Attach a current-measuring probe to terminal 6 of the wire harness.
- (c) Turn the ignition switch ON, and set the power window switch in the down position.
- (d) As the window goes down, check that the current flow is up to approximately 7 A.



- (e) Check that the current increases approximately 14.5 A or more when the window stops going down.
HINT: The circuit breaker opens some 4-40 seconds after the window stops going down, so check must be made before the circuit breaker operates.
If operation is as specified, replace the master switch.




POWER WINDOW SWITCH INSPECTION

INSPECT SWITCH CONTINUITY

Switch position	Tester connection to terminal number	Specified condition
UP	1 - 5 3 - 4	Continuity
OFF	1 - 2 3 - 4	Continuity
DOWN	1 - 2 4 - 5	Continuity

If continuity is not as specified, replace the switch.



POWER WINDOW MOTOR INSPECTION

1. INSPECT LEFT SIDE DOOR MOTOR OPERATION

Front Door



- Connect the positive (+) lead from the battery to terminal 3 and the negative (-) lead to terminal 1, and check that the motor turns clockwise.
- Reverse the polarity, and check that the motor turns counterclockwise.

If operation is not as specified, replace the motor.

Rear Door

- Connect the positive (+) lead from the battery to terminal 1 and the negative (-) lead to terminal 2, and check that the motor turns counterclockwise.
- Reverse the polarity, and check that the motor turns clockwise.


If operation is not as specified, replace the motor.




2. INSPECT LEFT SIDE CIRCUIT BREAKER OPERATION

Driver's Door



- Disconnect the connector from the master switch.
- Connect the positive (+) lead from the battery to terminal 6 and the negative (-) lead to terminal 13 on the wire harness side connector and raise the window to full closed position.
- Continue to apply voltage, and check that there is a circuit breaker operation noise within approximately 4 to 40 seconds.
- Reverse the polarity, and check that the window begins to descend within approximately 60 seconds. If operation is not as specified, replace the motor.





Passenger's Door


- Disconnect the connector from the power window switch.
 - Connect the positive (+) lead from the battery to terminal 1 and the negative (-) lead to terminal 4 on the wire harness side connector, and raise the window to full closed position.
 - Continue to apply voltage, and check that there is a circuit breaker operation noise within approximately 4 to 40 seconds.
 - Reverse the polarity, and check that the window begins to descend within approximately 60 seconds.
- If operation is not as specified, replace the motor.



3. INSPECT RIGHT SIDE DOOR MOTOR OPERATION

Front Door

- Connect the positive (+) lead from the battery to terminal 1 and the negative (-) lead to terminal 3, and check that the motor turns clockwise.
- Reverse the polarity, and check that the motor turns counterclockwise.




Rear Door

- Connect the positive (+) lead from the battery to terminal 2 and the negative (-) lead to terminal 1, and check that the motor turns counterclockwise.
- Reverse the polarity, and check that the motor turns clockwise.

If operation is not as specified, replace the motor.

INSPECT RIGHT SIDE CIRCUIT BREAKER OPERATION

See step of left side motor on page [BE-57](#)



POWER MAIN RELAY INSPECTION

INSPECT RELAY CONTINUITY

Condition	Tester connection to terminal number	Specified condition
Constant	1 - 3	Continuity
Apply B + between terminals 1 and 3.	2 - 4	Continuity

If continuity is not as specified, replace the relay.