






ON-VEHICLE INSPECTION SPARK TEST

CHECK THAT SPARK OCCURS

- Disconnect the high-tension cords (from the ignition coil) from the distributor cap.
 - Hold the end approx. 12.5 mm (0.50 in.) from the body ground.
 - Check if spark occurs while engine is being cranked.
- HINT: To prevent gasoline from being injected from injectors during this test, crank the engine for no more than 1–2 seconds at a time.

If the spark does not occur, do the test as follows:






HIGH-TENSION CORDS INSPECTION


1. REMOVE NO.2 PCV HOSE
2. REMOVE AIR CLEANER HOSE
3. DISCONNECT THROTTLE CABLE
4. REMOVE NO.2 AND NO.3 CYLINDER HEAD COVERS

Remove the 4 bolts and head covers.




5. DISCONNECT HIGH-TENSION CORDS FROM SPARK PLUGS

- (a) Remove the 2 mounting bolts of the No.1 and No.2 cord clamps.




- (b) Disconnect the high-tension cords at the rubber boot.
DO NOT pull on the cords.

NOTICE: Pulling on or bending the cords may damage the conductor inside.



6. DISCONNECT HIGH-TENSION CORDS FROM DISTRIBUTOR CAP AND IGNITION COIL


- (a) Using a screwdriver, lift up the lock claw and disconnect the holder from the distributor cap (ignition coil).



- (b) Disconnect the high-tension cord at the grommet.
DO NOT pull on the cord.

NOTICE:

- Pulling on or bending the cords may damage the conductor inside.
- Do not wipe any of the oil from the grommet after the high-tension cord is disconnected.




7. INSPECT HIGH-TENSION CORD RESISTANCE

Using an ohmmeter, measure the resistance.

Maximum resistance:


25 k Ω per cord

If the resistance is greater than maximum, check the terminals. If necessary, replace the high-tension cord.




8. RECONNECT HIGH-TENSION CORDS TO DISTRIBUTOR CAP AND IGNITION COIL


- (a) Assemble the holder and grommet.




HINT: Connect the high-tension cords to the distributor cap as shown in the illustration.



- (b) Align the spline of the distributor (ignition coil) with the spline of the holder, and push in the cord.





NOTICE: Check that the holder is correctly installed to the grommet and distributor cap as shown in the illustration.




- (c) Check that the lock claw of the holder is engaged by lightly pulling the holder.

9. RECONNECT HIGH-TENSION CORDS TO SPARK PLUGS

- (a) Secure the high-tension cords with the cord clamps as shown in the illustration.



- (b) Install the No.1 and No.2 cord clamps with the 2 bolts.



10. INSTALL NO.2 AND NO.3 CYLINDER HEAD COVERS


Install the head covers with the 4 bolts.

11. CONNECT THROTTLE CABLE

12. INSTALL AIR CLEANER HOSE

Install the air cleaner hose with the 2 clamp bolts.

13. INSTALL NO.2 PCV HOSE




SPARK PLUGS INSPECTION

1. **DISCONNECT HIGH-TENSION CORDS FROM SPARK PLUGS** (See steps 1 to 5 in high-tension cords inspection)


2. **REMOVE SPARK PLUGS**

Using a 16 mm plug wrench, remove the spark plug.



3. **CLEAN SPARK PLUGS**

Using a spark plug cleaner or wire brush, clean the spark plug.



4. **VISUALLY INSPECT SPARK PLUGS**


Check the spark plug for electrode wear, threads damage and insulator damage.

If abnormal, replace the plugs.

Recommended spark plugs:

ND: K16R-U

NGK: BKR5EYA




5. **ADJUST ELECTRODE GAP**

Carefully bend the outer electrode to obtain the correct electrode gap.

Correct electrode gap:

0.8 mm (0.031 in.)



6. **INSTALL SPARK PLUGS**

Using a 16 mm plug wrench, install the spark plug.


Torque: 20 N·m (200 kgf·cm, 14 ft·lbf)

7. **RECONNECT HIGH-TENSION CORDS TO SPARK PLUGS** (See steps 9 to 13 in high-tension cords inspection)

IGNITION COIL INSPECTION

NOTICE: "Cold" and "Hot" in the following sentences express the temperature of the coils themselves. "Cold" is from -10°C (14°F) to 50°C (122°F) and "Hot" is from 50°C (122°F) to 100°C (212°F).

1. **DISCONNECT IGNITION COIL CONNECTOR**
2. **DISCONNECT HIGH-TENSION CORD**



3. INSPECT PRIMARY COIL RESISTANCE


Using an ohmmeter, measure the resistance between the positive (+) and negative (-) terminals.

Primary coil resistance:

Cold: $0.36 - 0.55 \Omega$

Hot: $0.45 - 0.65 \Omega$

If the resistance is not as specified, replace the ignition coil.



4. INSPECT SECONDARY COIL RESISTANCE

Using an ohmmeter, measure the resistance between the positive (+) and high-tension terminals.

Secondary coil resistance:

Cold: $9.0 - 15.4 \text{ k}\Omega$

Hot: $11.4 - 18.1 \text{ k}\Omega$

If the resistance is not as specified, replace the ignition coil.

5. **RECONNECT HIGH-TENSION CORD**
6. **RECONNECT IGNITION COIL CONNECTOR**

DISTRIBUTOR INSPECTION

NOTICE: "Cold" and "Hot" in the following sentences express the temperature of the coils themselves. "Cold" is from -10°C (14°F) to 50°C (122°F) and "Hot" is from 50°C (122°F) to 100°C (212°F).




1. **DISCONNECT DISTRIBUTOR CONNECTOR**
2. **REMOVE DISTRIBUTOR CAP WITHOUT DISCONNECTING HIGH-TENSION CORDS**
3. **REMOVE ROTOR**
4. **INSPECT AIR GAPS**

Using a thickness gauge, measure the gap between the signal rotor and the pickup coil projection.

Air gap:

0.2 – 0.4 mm (0.008 – 0.016 in.)

If the gap is not as specified, replace the distributor housing.



5. **INSPECT SIGNAL GENERATOR (PICKUP COIL) RESISTANCE**

Using an ohmmeter, check that the resistance of the pickup coil.

Pickup coil resistance:

Cold:

G1 and G $\ominus$: 185 – 275 Ω

G2 and G $\ominus$: 185 – 275 Ω

NE and G $\ominus$: 185 – 275 Ω

Hot:

G1 and G $\ominus$: 240 – 325 Ω

G2 and G $\ominus$: 240 – 325 Ω

NE and G $\ominus$: 240 – 325 Ω

If the resistance is not as specified, replace the distributor housing.


6. **REINSTALL ROTOR**
7. **REINSTALL DISTRIBUTOR CAP**
8. **RECONNECT DISTRIBUTOR CONNECTOR**

CRANKSHAFT POSITION SENSOR INSPECTION

NOTICE: "Cold" and "Hot" in the following sentences express the temperature of the sensor itself.

"Cold" is from -10°C (14°F) to 50°C (122°F) and "Hot" is from 50°C (122°F) to 100°C (212°F).

1. **DISCONNECT CRANKSHAFT POSITION SENSOR CONNECTOR AND BRACKET**



2. **INSPECT CRANKSHAFT POSITION SENSOR RESISTANCE**

Using an ohmmeter, measure the resistance between the terminals.

Resistance (NE $\oplus$ -NE $\ominus$):

Cold: 1,630 – 2,740 Ω

Hot: 2,065 – 3,225 Ω

If the resistance is not as specified, replace the crankshaft position sensor.

3. **RECONNECT CRANKSHAFT POSITION SENSOR BRACKET AND CONNECTOR**

IGNITER INSPECTION

(See Spark Test in on-vehicle inspection)