


HEADLIGHT



SERVICE HINTS

HEAD RELAY

(2) 1- (2) 2: CLOSED WITH THE LIGHT CONTROL SW AT **HEAD** POSITION OR DIMMER SW AT **FLASH** POSITION

C14 LIGHT CONTROL SW [COMB. SW]

13-11 : CLOSED WITH THE LIGHT CONTROL SW AT **HEAD** POSITION

C14 DIMMER SW [COMB. SW]

14-9 : CLOSED WITH THE DIMMER SW AT **FLASH** POSITION

12-9 : CLOSED WITH THE DIMMER SW AT **HIGH** OR **FLASH** POSITION



: PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
C13	24	H 1	22	J 7	25
C14	24	H 2	22	L 1	25
D 7	24	H 3	22		
F 8	22	H 4	22		



: RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	18	R/B NO. 2 (FRONT SIDE OF LEFT FENDER)



: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
EA2	30	COWL WIRE AND ENGINE ROOM MAIN WIRE (LEFT FENDER)
EA3		



: GROUND POINTS


CODE	SEE PAGE	GROUND POINTS LOCATION
EA	30	FRONT SIDE OF RIGHT FENDER
EB	30	FRONT SIDE OF LEFT FENDER
ID	32	LEFT KICK PANEL




: SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
E 2	30	ENGINE ROOM MAIN WIRE	E 5	30	ENGINE ROOM MAIN WIRE
E 3			I 1	32	COWL WIRE
E 4			I 6		


C13



C14 BLACK



D 7 ORANGE



F 8




H 1, H 2 BLACK




H 3, H 4 BROWN



J 7 BLUE



L 1



(HINT : SEE PAGE 7)