



(1) 2–(1) 3: CLOSED WITH THE LIGHT CONTROL SW AT TAIL OR HEAD POSITION



CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
C14	24	J 7	25	P 3	23
F 8	22	L 1	25	R 8	27
F11	25	L 2	26	R 9	27
J 1	25	P 2	23	T 4	27

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
1	20	R/B NO. 1 (LEFT KICK PANEL)

CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
EA3	30	COWL WIRE AND ENGINE ROOM MAIN WIRE (LEFT FENDER)
ID2	32	COWL WIRE AND FLOOR NO. 1 WIRE (LEFT KICK PANEL)
BQ1	34	FLOOR NO. 3 WIRE AND FLOOR NO. 1 WIRE (LEFT QUARTER PANEL INNER)
BV1	36	LUGGAGE ROOM NO. 3 WIRE AND FLOOR NO. 3 WIRE (UNDER THE LOWER BACK PANEL)

CODE	SEE PAGE	GROUND POINTS LOCATION
EA	30	FRONT SIDE OF RIGHT FENDER
EB	30	FRONT SIDE OF LEFT FENDER
ID	32	LEFT KICK PANEL
BG	34	LOWER BACK PANEL CENTER

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
E 5	30	ENGINE ROOM MAIN WIRE	B32	36	FLOOR NO. 3 WIRE
B31	36	FLOOR NO. 3 WIRE	B34		



(SEE PAGE 20)

