


REMOVAL

1. REMOVE FRONT AXLE HUB (See page SA-7)

2. REMOVE ABS SPEED SENSOR

Remove the 2 bolts and disconnect the speed sensor from the steering knuckle.



W00495

3. REMOVE DUST SEAL AND DUST COVER


Remove the 8 bolts, dust seal, dust cover and gasket.

4. REMOVE KNUCKLE SPINDLE

- (a) Using a brass bar and hammer, tap the knuckle spindle of the steering knuckle.
- (b) Remove the knuckle spindle and gasket.

5. REMOVE AXLE SHAFT


Position one flat part of the outer shaft upward and remove the axle shaft.



SA2644

6. DISCONNECT TIE ROD FROM KNUCKLE ARM


- (a) Remove the cotter pin and nut.
- (b) Using SST, disconnect the tie rod from the knuckle arm.
SST 09611-22012



R08383

7. REMOVE OIL SEAL SET


- (a) Remove the 6 bolts from the end retainer.
- (b) Remove these parts from the steering knuckle:
 - Oil seal end retainer
 - Felt dust seal
 - Rubber seal
 - Steel ring



R13137

8. REMOVE KNUCKLE ARM AND BEARING CAP

- (a) Remove the 2 bolts and plate washers from the bearing cap.
- (b) Remove the 4 nuts from the knuckle arm.
- (c) Using a brass bar and hammer, tap on the 4 bolts heads and remove the 4 cone washers.




- (d) Using SST, remove the bearing cap and shim from the steering knuckle.

SST 09606-60020

HINT:

- Use the SST without a collar.
- In some cases, to satisfy the standard value of preload, more than one shims are used.



- (e) Using SST, remove the knuckle arm and shim from the steering knuckle.

SST 09606-60020


HINT:

- Use the SST without a collar.
- In some cases, to satisfy the standard value of preload, more than one shims are used.

9. REMOVE STEERING KNUCKLE AND BEARING

HINT:

Mark the removed adjusting shim and bearings so as to enable reassembling them to their proper positions.



10. REMOVE OIL SEAL TO AXLE HOUSING

Using SST, remove the oil seal.

SST 09308-00010