


CIRCUIT DESCRIPTION

WIRING DIAGRAM




INSPECTION PROCEDURE

1	Check operation of stop light.
---	--------------------------------

Check that stop light lights up when brake pedal is depressed and turns off when brake pedal is released.

Repair stop light circuit (See page [BE-24](#)).

OK

2 Check voltage between terminal STP of ABS ECU and body ground.**PREPARATION:**

Remove ABS ECU with connectors still connected.

CHECK:

Measure voltage between terminal STP of ABS ECU and body ground when brake pedal is depressed.

OK:

Voltage: 8 - 14 V

OK

Proceed to next circuit inspection shown on problem symptoms table (See page [DI-199](#)).

NG

3 Check for open in harness and connector between ABS ECU and stop light switch (See page [IN-27](#)).

NG

Repair or replace harness or connector.

OK

Check and replace ABS ECU.