

|            |              |                                    |
|------------|--------------|------------------------------------|
| <b>DTC</b> | <b>P0171</b> | <b>System too Lean (Fuel Trim)</b> |
|------------|--------------|------------------------------------|

|            |              |                                    |
|------------|--------------|------------------------------------|
| <b>DTC</b> | <b>P0172</b> | <b>System too Rich (Fuel Trim)</b> |
|------------|--------------|------------------------------------|

## CIRCUIT DESCRIPTION

"Fuel trim" refers to the feedback compensation value compared against the basic injection time. Fuel trim includes short-term fuel trim and long-term fuel trim.

"Short-term fuel trim" is the short-term fuel compensation used to maintain the air-fuel ratio at its ideal theoretical value. The signal from the heated oxygen sensor indicates whether the air-fuel ratio is RICH or LEAN compared to the ideal theoretical value, triggering a reduction in fuel volume if the air-fuel ratio is rich, and an increase in fuel volume if it is lean.

"Long-term fuel trim" is overall fuel compensation carried out long-term to compensate for continual deviation of the short-term fuel trim from the central value due to individual engine differences, wear over time and changes in the usage environment.

If both the short-term fuel trim and long-term fuel trim are LEAN or RICH beyond a certain value, it is detected as a malfunction and the MIL lights up.

| DTC No. | DTC Detecting Condition                                                                                                                                  | Trouble Area                                                                                                                                                                                                                                                                     |
|---------|----------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| P0171   | When the air fuel ratio feedback is stable after engine warming up, the fuel trim is considerably in error on the LEAN side.<br>(2 trip detection logic) | <ul style="list-style-type: none"> <li>• Air intake (hose loose)</li> <li>• Fuel line pressure</li> <li>• Injector blockage, leak</li> <li>• Heated oxygen sensor (bank 1 sensor 1) malfunction</li> <li>• Mass air flow meter</li> <li>• Engine coolant temp. sensor</li> </ul> |
| P0172   | When the air fuel ratio feedback is stable after engine warming up, the fuel trim is considerably in error on the RICH side.<br>(2 trip detection logic) | <ul style="list-style-type: none"> <li>• Fuel line pressure</li> <li>• Injector blockage, leak</li> <li>• Heated oxygen sensor (bank 1 sensor 1) malfunction</li> <li>• Mass air flow meter</li> <li>• Engine coolant temp. sensor</li> </ul>                                    |

### HINT:

- When the DTC P0171 is recorded, the actual air-fuel ratio is on the LEAN side. When DTC P0172 is recorded, the actual air-fuel ratio is on the RICH side.
- If the total of the short-term fuel trim value and long-term fuel trim value is within + 30 – – 35 %, the system is functioning normally.
- If the vehicle runs out of fuel, the air-fuel ratio is LEAN and DTC P0171 is recorded. The MIL then come on.

## INSPECTION PROCEDURE

|          |                                                                    |
|----------|--------------------------------------------------------------------|
| <b>1</b> | <b>Check air induction system (See page <a href="#">SF-1</a>).</b> |
|----------|--------------------------------------------------------------------|

NG

Repair or replace

OK

|   |                                                               |
|---|---------------------------------------------------------------|
| 2 | <b>Check for heated oxygen sensor (bank 1 sensor 1) data.</b> |
|---|---------------------------------------------------------------|

**PREPARATION:**

- (a) Remove the fuse cover on the instrument panel.
- (b) Connect the OBD II scan tool or TOYOTA hand-held tester to the DLC3.
- (c) Warm up engine to normal operating temperature.

**CHECK:**

Read the heated oxygen sensor (bank 1 sensor 1) output voltage and short-term fuel trim.

**RESULT:**

| Pattern | Heated oxygen sensor (bank 1 sensor 1) output voltage | Short-term fuel trim   |
|---------|-------------------------------------------------------|------------------------|
| 1       | Lean condition (Changes at 0.55 V or less)            | Changes at about +20 % |
| 2       | Rich condition (Changes at 0.4 V or more)             | Changes at about -20 % |
| 3       | Except 1 and 2                                        |                        |

3

**Check for heated oxygen sensor (bank 1 sensor 1) (See page SF-63).**

1, 2

|   |                                             |
|---|---------------------------------------------|
| 3 | <b>Check fuel pressure (See page SF-6).</b> |
|---|---------------------------------------------|

NG

**Check and repair fuel pump, pressure regulator, fuel pipe line and filter (See page SF-1).**

OK

|   |                                                   |
|---|---------------------------------------------------|
| 4 | <b>Check injector injection (See page SF-28).</b> |
|---|---------------------------------------------------|

NG

**Replace injector.**

OK

|   |                                                                                                                         |
|---|-------------------------------------------------------------------------------------------------------------------------|
| 5 | Check mass air flow meter and engine coolant temp. sensor<br>(See page <a href="#">SF-39</a> , <a href="#">SF-60</a> ). |
|---|-------------------------------------------------------------------------------------------------------------------------|

NG

Repair or replace.

OK

|   |                                                                |
|---|----------------------------------------------------------------|
| 6 | Check for spark and ignition (See page <a href="#">IG-1</a> ). |
|---|----------------------------------------------------------------|

NG

Repair or replace.

OK

Check and replace ECM (See page [IN-27](#)).