



SERVICE HINTS

C 6 CIGARETTE LIGHTER

- 2-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT **ACC** OR **ON** POSITION
 1-GROUND : ALWAYS CONTINUITY

C 9 CLOCK

- 3-GROUND : ALWAYS APPROX. 12 VOLTS (POWER FOR CLOCK)
 4-GROUND : APPROX. 12 VOLTS WITH THE IGNITION SW AT **ACC** OR **ON** POSITION (POWER FOR INDICATION)
 2-GROUND : APPROX 12 VOLTS WITH THE LIGHT CONTROL SW AT **TAIL** OR **HEAD** POSITION
 1-GROUND : ALWAYS CONTINUITY

○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
C 6	24	J 3	25	J 8	25
C 9	24	J 4	25		
F11	25	J 7	25		

○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	18	R/B NO.2 (FRONT SIDE OF THE LEFT FENDER)

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS



CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
EA1	30	COWL WIRE AND ENGINE ROOM MAIN WIRE (LEFT FENDER)

▽ : GROUND POINTS


CODE	SEE PAGE	GROUND POINTS LOCATION
ID	32	LEFT KICK PANEL
IE	32	RIGHT KICK PANEL

○ : SPLICE POINTS


CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
I 8	32	COWL WIRE			




F11
(SEE PAGE 20)




(HINT : SEE PAGE 7)



(HINT : SEE PAGE 7)



(HINT : SEE PAGE 7)



(HINT : SEE PAGE 7)