

Clutch System

GENERAL	CH -2
CLUTCH SYSTEM	CH -6

GENERAL

SPECIFICATIONS

EOKB1010

Clutch operating method	Hydraulic type
Clutch disc	
Type	Single dry with diaphragm.
Facing diameter (Outside x Inside) mm (in.)	215 x 145 (8.5 x 5.7)
Clutch cover assembly	
Type	Diaphragm spring strap
Clutch release cylinder	
* I.D. mm (in.)	20.64 (0.81)
Clutch master cylinder	
* I.D. mm (in.)	15.87(0.62)

* I.D. : Inside Diameter

SERVICE STANDARD

EONC0020

Clutch disc thickness [When free]	8.5 ± 0.3
Clutch pedal free play	6-13 (0.24-0.52)
Clutch pedal height	182.7 (7.3)
Clutch pedal stroke	140 (5.6)
Limit	
Clutch disc rivet sink	1.1 mm (0.044 in.)
Diaphragm spring end height difference	0.5 mm (0.02 in.)
Clutch release cylinder clearance to piston	0.15 mm (0.006 in.)
Clutch master cylinder clearance to piston	0.15 mm (0.006 in.)

Unit : mm (inch)


TIGHTENING TORQUE EONC0030

Item	Nm	kg.cm	lb.ft
Clutch pedal to pedal support member	17-26	170-260	13-18
Clutch pedal support member to master cylinder	17-26	170-260	13-18
Clutch tube flare nut	13-17	130-170	9-13
Clutch tube bracket	4-6	40-60	3-4
Reservoir band	5-7	50-70	3-5
Clutch release cylinder	15-22	150-220	11-16
Clutch release cylinder union bolt	20-25	200-250	15-18
Clutch cover assembly	15-22	150-220	11-16

LUBRICANTS EONC0040

Items	Specified lubricants	Quantity
Contact surface of release bearing and fulcrum of clutch release fork	CASMOLY L9508	As required
Inner surface of clutch release bearing	CASMOLY L9508	As required
Inner surface of clutch release cylinder and outer circumference of piston and cup	Brake fluid DOT3 or DOT4	As required
Inner surface of clutch disc spline	CASMOLY L9508	As required
Inner surface of clutch master cylinder and outer circumference of piston assembly	Brake fluid DOT3 or DOT4	As required
Clutch master cylinder push rod, clevis pin and washer	Wheel bearing grease SAE J310a, NLGI No.2	As required
Clutch pedal shaft and bushings	SAE J310a, Chassis grease, NLGI-No.1	As required
Contact portion of release fork to release cylinder push rod	CASMOLY L9508	As required
Input shaft spline	CASMOLY L9508	As required

SPECIAL TOOLS EODA0050

Tool (Number and name)	Illustration	Use
09411-25000 Clutch disc guide	 EODA003A	Installation of the clutch disc

TROUBLESHOOTING

EODA0060

Symptom		Probable cause	Remedy
Clutch slipping		Insufficient clutch pedal free play Clogged hydraulic system Excessive wear of clutch disc facing Hardened clutch disc facing, or oil on surface Damaged pressure plate or flywheel Weak or broken pressure spring	Adjust Correct or replace parts Replace Replace Replace Replace
Difficult gear shifting (gear noise during shifting)		Excessive pedal free play Hydraulic system fluid leaks, air trapping or clogging Unusual wear or corrosion of clutch disc spline Excessive vibration (distortion) of clutch disc	Adjust Repair or replace parts Replace Replace
Clutch noisy	When clutch is not used	Insufficient play of clutch pedal Excessive wear of clutch disc facing	Adjust Replace
	A noise is heard after clutch is disengaged	Unusual wear and/or damage of release bearing	Replace
	A noise is heard when clutch is disengaged	Insufficient grease on the sliding surface of bearing sleeve Improperly installed clutch assembly or bearing	Repair Repair
	A noise is heard when car is suddenly rolled with clutch partially engaged	Damaged pilot bushing	Replace
Difficult to depress clutch pedal		Insufficient lubrication of clutch pedal Insufficient lubrication of the clutch disc spline Insufficient lubrication of the clutch release lever shaft Insufficient lubrication of front bearing retainer	Repair Repair Repair Repair
Difficult to shift gear or cannot shift at all		Excessive clutch pedal free play excessive Clutch release cylinder faulty Clutch disc out of true, runout is excessive or lining broken Spline on input shaft or clutch disc dirty or burred Clutch pressure plate faulty	Adjust pedal free play Repair release cylinder Inspect clutch disc Repair as necessary Replace clutch cover
Clutch slips		Clutch pedal free play insufficient Clogged hydraulic system Clutch disc lining oily or worn out Pressure plate faulty Release fork binding	Adjust pedal free play Repair or replace parts Inspect clutch disc Replace clutch cover Inspect release fork

Symptom	Probable cause	Remedy
Clutch grabs/chatters	Clutch disc lining oily or worn out Pressure plate faulty Clutch diaphragm spring bent Worn or broken torsion spring Engine mounts loose	Inspect clutch disc Replace clutch cover Replace clutch cover Replace clutch disc Repair as necessary
Clutch noisy	Damaged clutch pedal bushing Loose part inside housing Release bearing worn or dirty Release fork or linkage sticks	Replace clutch pedal bushing Repair as necessary Replace release bearing Repair as necessary

CLUTCH SYSTEM

EONB0070

BLEEDING

Whenever the clutch tube, the clutch hose, and/or the clutch master cylinder have been removed, or if the clutch pedal is spongy, bleed the system.


CAUTION

Use the specified fluid. Avoid mixing different brands of fluid. Specified fluid : SAE J1703 (DOT3 or DOT4).

1. Loosen the bleeder screw at the clutch release cylinder.
2. Push the clutch pedal down slowly until all is expelled.
3. Hold the clutch pedal down until the bleeder is retightened.
4. Refill the clutch master cylinder with the specified fluid.

CAUTION


The rapidly-repeated operation of the clutch pedal in B-C range may cause the release cylinder's position to be forced out from the release cylinder body during air bleeding. Repress the clutch pedal after it returns to the "A" point completely.



EODA007C

CLUTCH COVER AND DISC

COMPONENTS EODA0280




TORQUE : Nm (kg·cm,lb·ft)

EODA017A

REMOVAL EODA1290

1. Drain the clutch fluid and transaxle gear oil.
2. Remove the transaxle assembly.
3. Insert the special tool (09411-25000) in the clutch disc to prevent the disc from falling.
4. Loosen the bolts that attach the clutch cover to the flywheel in a star pattern.
5. Loosen the bolts in succession, one or two turns at a time, to avoid bending the cover flange.



EODA117B

 **CAUTION**

DO NOT clean the clutch disc or release bearing with cleaning solvent.

INSPECTION EODA0300

CLUTCH COVER ASSEMBLY

- Check the diaphragm spring end for wear and uneven height.
Replace if wear is evident or height difference exceeds the limit.


Limit : 0.5 mm (0.012 in.)

- Check the pressure plate surface for wear, cracks and color change.
- Check the rivets for looseness and replace the clutch cover assembly if necessary.

CLUTCH DISC

- Check the clutch facing for loose rivets, uneven contact, deterioration due to seizure, adhesion of oil, or grease, and replace the clutch disc if defective.
- Measure the rivet sink and replace the clutch disc if it is out of specification

Limit : 1.1 mm (0.044 in.)



EODA018A

- Check for torsion spring play and damage and if defective, replace the clutch disc.
- Clean the splines on the input shaft and install the clutch disc.
If the disc does not slide smoothly or if play is excessive, replace the clutch disc and/or the input shaft.

CLUTCH RELEASE BEARING



CAUTION

The release bearing is packed with grease. Do not use cleaning solvent or oil.

- Check the bearing for seizure, damage or abnormal noise. Also check the diaphragm spring contacting points for wear.

- Replace the bearing if the release fork contacting points are worn abnormally.

CLUTCH RELEASE FORK


If there is abnormal wear at the point of contact with the bearing, replace the release fork assembly.

INSTALLATION EONC1310

- Apply multipurpose grease to the release bearing contact surfaces and the release cylinder contact surface of the clutch release fork assembly.




When installing the clutch, apply grease to each part, but be careful not to apply excessive grease. It can cause clutch slippage and judder.



EODA019B

- Apply multipurpose grease into the groove of the release bearing.

Grease : CASMOLY L9508



EODA019A

- Apply multipurpose grease to the clutch release lever fulcrum contact surface of the clutch release fork assembly.

Grease : CASMOLY L9508

4. Clean the surfaces of the flywheel and pressure plate thoroughly with fine sandpaper or crocus cloth, and make certain that all oil or grease has been removed.
5. Apply a small amount of multipurpose grease to the clutch disc splines and input shaft splines.


Grease : CASMOLY L9508



CAUTION

Do not apply more grease than necessary. Too much grease could cause clutch slip or judder.

6. Using the special tool (09411-25000), install the clutch disc to the flywheel. When installing the clutch disc, be sure that the surface having the manufacturer's stamp is towards the pressure plate side.
7. Install the clutch cover assembly onto the flywheel and install the six (6) bolts through the clutch cover into the flywheel.
8. Diagonally tighten the bolts 15–22 Nm (150–220 kg.cm, 11–15 lb.ft).
Tighten the bolts by one or two turns at a time, in succession, to avoid bending the cover flange.
9. Remove the special tool.
10. Install the transaxle.
11. Adjust the clutch pedal free-play.




EODA120A

CLUTCH MASTER CYLINDER

COMPONENTS

EONB0170



TORQUE : Nm (kg·cm, lb·ft)

EONB017A

DISASSEMBLY

EODA0180

1. Remove the reservoir band, reservoir tank and reservoir cap.
2. Remove the piston stop ring.
3. Pull out the push rod and piston assembly.

 **NOTE**

Be careful not to damage the master cylinder body and piston assembly.

INSPECTION

EONC0190


1. Check the inside of the cylinder body for rust, pitting or scoring.
2. Check the piston cup for wear or distortion.
3. Check the piston for rust, pitting or scoring.
4. Check the clutch tube line for obstructions.
5. Measure the clutch master cylinder inside diameter with a cylinder gauge, and the piston outside diameter with a micrometer.

 **NOTE**

Measure the inside diameter of the clutch master cylinder in three places (bottom, middle, and top), in perpendicular directions.

6. If the clutch master cylinder-to-piston clearance exceeds the limit, replace the master cylinder and/or piston assembly.

Limit : 0.15 mm (0.006 in.)



EODA014A



REASSEMBLY

EONC0200

1. Apply the specified fluid to the inner surface of the cylinder body and to the outside of the piston assembly.


Specified fluid : BRAKE FLUID DOT 3 or DOT4

2. Install the piston assembly.
3. Install the piston stop ring.
4. Install the push rod assembly.



EODA014B

5. Install the reservoir band, reservoir tank and reservoir cap.



EODA014C

CLUTCH PEDAL

SERVICE ADJUSTMENT

PROCEDURE EONC0070


CLUTCH PEDAL INSPECTION AND ADJUSTMENT

1. Measure the clutch pedal height (from the face of the pedal pad to the floorboard).

Standard value :


(A) 182.7 mm (7.3 in.)

Clutch pedal clevis pin play




EONC007A

Clutch pedal free play



EONC007B

2. If the clutch pedal height is not within the standard value range, adjust as follows :
 - Turn and adjust the bolt, then secure by tightening the lock nut.



EODA006B



NOTE

After the adjustment, tighten the bolt until it reaches the pedal stopper, and then tighten the lock nut.



- Turn the push rod to agree with the standard value and then secure the push rod with the lock nut.



CAUTION

When adjusting the clutch pedal height be careful not to push the push rod toward the master cylinder.

COMPONENTS EONC0080



TORQUE : Nm (kg·cm, lb·ft)

REMOVAL EONC0090

1. Remove the cotter pin, washer.
2. Remove the clutch pedal mounting bolt.

INSPECTION EONC0100

1. Check the clutch pedal shaft and bushing for wear.
2. Check the clutch pedal for bending or distortion.
3. Check the return spring for damage or deterioration.
4. Check the clutch pedal pad for damage or wear.

IGNITION LOCK SWITCH INSPECTION


Check for continuity between terminals.

Condition	Terminal	1	2
Pushed		○	—
Free		—	○

EODA009A


INSTALLATION EONC0110

1. Apply to the multi-purpose grease the bushing.



<Gasoline>


EONC011A



<Diesel>

EONC011B

2. Install the bolt and nut.




EONC010A

CLUTCH RELEASE CYLINDER

COMPONENTS

EODA0210



EODA015A

REMOVAL

EODA0220

1. Disconnect the clutch tube.
2. Remove the clutch release cylinder mounting bolt.

INSPECTION

EODA0230

1. Check the clutch release cylinder for fluid leakage.
2. Check the clutch release cylinder boots for damage.


DISASSEMBLY

EODA0240

1. Remove the clutch hose, valve plate, spring, push rod and boot.
2. Remove any dirt from the piston bore opening of the release cylinder.
3. Remove the piston from the release cylinder using compressed air.

CAUTION

1. *Cover the release cylinder with rags to prevent the piston from popping out and causing injury.*
2. *Apply compressed air slowly to prevent the fluid from splashing in your eyes or on your skin.*




EODA016A

INSPECTION

EODA0250

1. Check the clutch release cylinder for fluid leakage.
2. Check the clutch release cylinder boots for damage.
3. Check the release cylinder bore for rust and damage.
4. Measure the release cylinder bore at three locations (bottom, middle and top) with a cylinder gauge and replace the release cylinder assembly if the bore-to-piston clearance exceeds the limit.

Limit : 0.15 mm (0.006 in.)



EODA016B


REASSEMBLY

EODA0260

1. Apply specified brake fluid to the release cylinder bore and the outer surface of the piston and piston cup, and push the piston cup assembly into the cylinder.

Use the specified fluid : Brake fluid DOT 3

2. Install the valve plate, push rod and boot.




EODA016C

INSTALLATION EODA1270


1. Coat the clevis pin with the specified grease.

Specified grease : CASMOLY L9508



EODA016D

2. Install the clutch release cylinder, and the clutch tube.



EODA011A