

Engine Electrical System

GENERAL	EE -2
IGNITION SYSTEM (DOHC)	EE -4
CHARGING SYSTEM	EE -10
STARTING SYSTEM	EE -28

GENERAL

SPECIFICATIONS EBNC0010

IGNITION COIL

Type	Mold dual coil
Primary coil resistance	$0.5 \pm 0.05\Omega$
Secondary coil resistance	$12.1 \pm 1.8k\Omega$

SPARK PLUG

Type	UNLEADED	LEADED
NGK	BKR5ES-11	BKR5ES
Champion	RC10YC4	RC10YC
Plug gap mm (in.)	1.0-1.1 (0.039-0.043)	0.7-0.8 (0.028-0.032)

STARTER MOTOR

Type	Reduction drive (with planetary gear)
Rated output	12V 0.9 kW, 1.2 kW
Rated time	30 sec.
No-load characteristics	
Terminal voltage	11.5V
Amperage	90A or less
Maximum speed	6,600 rpm or more
No. of pinion teeth	8
Pinion gap mm (in.)	0.5-2 (0.0197-0.079)

GENERATOR

Type	Battery voltage sensing
Rated output	13.5V 75A, 90A
Voltage regulator type	Electronic built-in type
Regulator setting voltage	$14.4 \pm 0.3V$
Temperature compensation	$-10 \pm 3mV/^{\circ}C$

BATTERY

Type	MF 45Ah	MF 60Ah
Ampere hours (5HR)	36 Ah or more	48 Ah or more
Ampere hours (20HR)	45 Ah or more	60 Ah or more
Cold cranking [at -17.8°C (0°F)]	380A or more	550A or more
Reserve capacity	80 min.	92 min.
Specific gravity [at 25°C (77°F)]	1.280 ± 0.01	1.280 ± 0.01

NOTE

COLD CRANKING AMPERAGE is the amperage that the battery can delivery for 30 seconds and maintain a terminal voltage of 7.2 volts or greater at a specified temperature.

RESERVE CAPACITY RATING is the amount of time a battery can deliver 25A and maintain a minimum terminal voltage of 10.5 volts at 26.7°C (80°F).

IGNITION SYSTEM (DOHC)


GENERAL INFORMATION

EBKB0150

Ignition timing is controlled by the electronic control ignition timing system. The standard reference ignition timing data for the engine operating conditions are pre-programmed in the memory of the engine control module (ECM).

The engine operating conditions (speed, load, warm-up condition, etc.) are detected by the various sensors. Based on these sensor signals and the ignition timing data, signals to interrupt the primary current are sent

to the ECM. The ignition coil is activated, and timing is controlled.



EBDA015A

TROUBLESHOOTING

Trouble condition	Probable cause	Remedy
Engine cranks, but will not start or is hard to start.	Ignition coil faulty High tension cable faulty Spark plugs faulty Incorrect immobilizer system Ignition wiring disconnected or broken	Replace ignition coil Replace high tension cable Replace plugs Adjust Inspect and replace
Rough idle or stalling	Spark plugs faulty Ignition wiring faulty Ignition coil faulty High tension cord faulty	Replace plugs Replace wiring Replace ignition coil Replace high tension cord
Engine hesitates/poor acceleration	Spark plugs faulty Ignition wiring faulty	Replace plugs Replace wiring
Poor fuel economy	Spark plugs faulty	Replace plugs

IGNITION SWITCH

EBKB0050

INSPECTION


1. Remove the connector located under the steering column.
2. Check for continuity between terminals.

Position	Key	Terminal	Ignition switch						Key lock solenoid	
			1	2	3	4	5	6		
LOCK	Removed									
ACC	Inserted		○	○					○	○
ON1			○	○	○	○	○	○		
START						○	○	○		

NOTE

○—○ indicates that there is continuity between the terminals.

EBDA005A



EBKB005A


IGNITION COILS

EBKB0170

CHECKING IGNITION COILS

1. Measure the primary coil resistance between terminals 1 and 2 of connectors C18-2 and C68-1 (the coils at the No.1 and No.4 cylinder sides) of the ignition coil, and between terminals 1 and 2 of connectors C18-1 and C68-2 (the coils at the No.2 and No.3 cylinder sides).

Standard value : $0.5 \pm 0.05\text{k}\Omega$




EBKB017A

2. Measure the secondary coil resistance between the high-voltage terminal for the No.1 and No.4 cylinders, and between the high-voltage terminals for the No.2 and No.3 cylinders.

Standard value : $12.1 \pm 1.8\text{k}\Omega$

CAUTION

When measuring the resistance of the secondary coil, be sure to disconnect the ignition coil connector.



EBDA017B

INSPECTION AND CLEANING OF SPARK PLUGS

EBDA0190

1. Disconnect the spark plug cables from the spark plugs.


NOTE

When removing the spark plug cable, pull on the spark plug cable boot (not the cable), as it may be damaged.

2. Using a spark plug socket, remove all spark plugs from the cylinder head.

CAUTION


Be careful that no contaminants enter through the spark plug holes.



EBDA019A

3. Check the spark plugs for the following :

- 1) Broken insulator
- 2) Worn electrode
- 3) Carbon deposits
- 4) Damaged or broken gasket
- 5) Condition of the porcelain insulator at the tip of the spark plug




EBDA009B

4. Check the spark plug gap using a wire gap gauge, and adjust if necessary.

Standard value :

1.0-1.1 mm (0.039-0.043 in.)




EBDA009C

5. Re- insert the spark plug and tighten to the specified torque.
If it is over torqued, damage to the threads of the cylinder head may result.

Tightening torque :

20-30 Nm (204-306 kg.cm, 15-21 lb.ft)



EBDA019A

ANALYZING SPARK PLUGS


Engine conditions can be analyzed by examining the tip deposits near the electrode.

Condition	Dark deposits	White deposits
Description	<ul style="list-style-type: none"> • Fuel mixture too rich • Low air intake 	<ul style="list-style-type: none"> • Fuel mixture too lean • Advanced ignition timing • Insufficient plug tightening

SPARK PLUG TEST (WHEN ENGINE CAN BE CRANKED)

Connect the spark plug cable. Ground the outer electrode (main body), and crank the engine. In the atmosphere, only short sparks are produced because of the small discharge gap. If the spark plug is good, however, sparks will occur in the discharge gap (between the electrodes). In

a defective spark plug, no sparks will occur because of a leak through the insulation.



EBDA019E


CHECKING SPARK PLUG CABLES

1. Check the cap and outer shell for cracks.
2. Measure the resistance


Spark plug cable				
CYLINDER	No.1	No.2	No.3	No.4
LENGTH (mm)	605	545	450	370
RESISTANCE (BOUGI) Ω	2.71-4.07	2.44-3.66	2.02-3.02	1.66-2.49
RESISTANCE (R16AIPS) Ω	6.05-12.71	5.45-11.45	4.50-9.45	3.70-7.77



NOTE
Resistance should not be higher than $10K\Omega$ per foot of cable. If resistance is higher, replace the cable.




EBDA019F

COMPONENT EBNC0230**TORQUE : Nm (kg.cm, lb.ft)**

EBDA023A

REMOVAL EBNC0240

1. Remove the ignition fuse (Fusible link-F (30A)).
2. Remove the rocker cover.
3. Disconnect the lead wire and spark plug cable.
4. Remove the ignition coil mounting bolt and remove the ignition coil assembly.
5. Installation is the reverse order of removal.




EBDA023B

**INSTALLATION SPARK PLUG
CABLE**

EBNC0250

Improper arrangement of spark plug cables will induce a voltage between the cables, causing misfire and develop a surge in acceleration during high-speed operation.

Therefore, be careful to arrange the spark plug cables properly.



EBDA023C


CHARGING SYSTEM

GENERAL INFORMATION

EBNC0260

The charging system includes a battery, a generator with a built-in regulator, and the charging indicator light and wire. The generator has six built-in diodes (three positive and three negative), each rectifying an AC current to DC current. Therefore, the DC current appears at generator "B" terminal.

In addition, the charging voltage of the generator is regulated by the battery voltage detection system. The main components of the generator are the rotor, stator, rectifier, capacitor brushes, bearings and drive belt pulley. The brush holder contains a built-in electronic voltage regulator.



EBDA024A


EBNC0270

TROUBLESHOOTING

Trouble condition	Probable cause	Remedy
Charging warning indicator does not light with ignition switch "ON" and engine off	Fuse blown Light burned out Wiring connection loose Electronic voltage regulator faulty	Check fuses Replace light Tighten loose connections Replace voltage regulator
Charging warning indicator does not go out with engine running. (Battery requires frequent recharging)	Drive belt loose or worn Battery cables loose, corroded or worn Fuse blown Fusible link blown Electronic voltage regulator or generator faulty Wiring faulty	Adjust tension or replace cables Repair or replace cables Check fuses Replace fusible link Test generator Repair wiring.
Discharged battery	Drive belt loose or worn Wiring connection loose or open circuit Fusible link blown Warning indicator and pre-excitation resistor faulty Poor grounding Electronic voltage regulator or generator faulty Battery life	Adjust tension or replace drive belt Tighten loose connection or repair wiring Replace fusible link Replace components Repair Test generator Replace battery
Overcharging	Electronic voltage regulator faulty Voltage sensing wire faulty	Replace voltage regulator Repair wire

CIRCUIT DIAGRAM FOR CHARGING SYSTEM

EBNC0280



INSPECTION OF CHARGING SYSTEM

EBDA0270

CHECKING POWER SOURCE CIRCUIT


The field coil excites the stator coil, which generates charging current.

TEST

1. Turn the ignition switch "ON".
2. With ignition switch "ON" (but engine off), ensure the charging indicator lamp is illuminated.
3. Disconnect the pre-excitation resistor connector. Connect an ohmmeter between terminals 1 and 3 (component side). Connect the (+) lead wire of the ohmmeter to terminal 3 and the (-) lead wire to terminal 1.

CAUTION

If the leads of the ohmmeter are not connected properly, there will be no reading on the ohmmeter. Be sure to connect the leads correctly.



COMPONENTS SIDE HARNESS SIDE

EBDA027A

RESULT

1. If there is continuity throughout steps 2 and 3, then the circuit is OK.
If there is continuity throughout steps 2 and 3, then the circuit, not the battery, is faulty.
2. If continuity is absent in step 2 only, then the charging indicator circuit should be checked and repaired. If continuity is absent during step 3 only then the pre-excitation register should be checked and replaced. (Refer to the circuit diagram).

NOTE

If continuity is absent in only one of steps 2 and 3, then the system is working normally. However, the individual circuit should be repaired for more reliable system operation.

VOLTAGE DROP TEST OF GENERATOR OUTPUT WIRE

EBDA0290

This test determines if the wiring between the generator "B" terminal and the battery (+) terminal is good by the voltage drop method.

PREPARATION

1. Turn the ignition switch to "OFF."

NOTE

To identify connection problems, be sure not to disturb either of the two terminals or their connections during this test.


2. Connect a digital voltmeter between the generator "B" terminal and battery (+) terminal. Connect the (+) lead wire of the voltmeter to the "B" terminal and the (-) lead wire to the battery (+) terminal.

CONDITIONS FOR TESTING

With the engine running and headlamps, blower motor etc. ON, check the reading on the voltmeter.

RESULT

1. The voltmeter should read a standard 0.3V.
2. If the reading is above 0.3V, poor wiring should be suspected.
Check wiring from generator 'B' terminal through the fusible link to the battery (+) terminal.
Check for loose wiring or color change from an over-heated harness. Correct and check again.
3. On completion of the test, set the engine at idle. Then turn off the headlamps, blower motor etc., and ignition.



EBDA029A

OUTPUT CURRENT TEST

EBDA0310

This test determines if the generator gives an output current that is equivalent to the nominal output.

PREPARATION

- Prior to the test, check the following items and correct as necessary.
 - Check if that the battery installed in the vehicle is in good condition. For details, see "BATTERY".

NOTE


The battery that is used to test the output current should be one that has been partially discharged. With a fully charged battery, the test may not be conducted correctly due to an insufficient load.

- Turn the ignition switch to "OFF".
- Disconnect the battery ground cable.
- Disconnect the generator output wire from the generator "B" terminal.
- Connect a DC ammeter (0 to 100A) in series between the "B" terminal and the disconnected output wire. Be sure to connect the (-) lead wire of the ammeter to the disconnected output wire.

NOTE

Tighten each connection securely, as a heavy current will flow. Do not rely on clips.

- Connect a voltmeter (0 to 20V) between the "B" terminal and ground. Connect the (+) lead wire to the generator "B" terminal and (-) lead wire to a good ground.
- Attach an engine tachometer and connect the battery ground cable.
- Leave the engine hood open.



EBDA031A

TEST

- Check to see that the voltmeter reads the same value as the battery voltage. If the voltmeter reads 0V, an open circuit in the wire between the generator "B" terminal and battery (-) terminal, a blown fusible link or poor ground is suspected.
- Start the engine and turn the headlights on.
- Set the headlights to high beam and the heater blower switch to HIGH, quickly increase the engine speed to 2,500 rpm and read the maximum output current value indicated by the ammeter.

NOTE

After the engine starts, the charging current quickly drops. Therefore, the above operation must be done quickly to read the maximum current value correctly.

RESULT

1. The ammeter reading must be higher than the limit value. If it is lower but the generator output wire is in good condition, remove the generator from the vehicle and test it.

Limit value

52.5 A min. : 75A generator
63.0 A min. : 90A generator

NOTE

1. *The nominal output current value is shown on the nameplate affixed to the generator body.*
2. *The output current value changes with the electrical load and the temperature of the generator itself. Therefore, the nominal output current may not be obtained. In such case, keep the headlights on to discharge the battery, or use the lights of another vehicle to increase the electrical load. The nominal output current may not be obtained if the temperature of the generator itself or ambient temperature is too high. In such a case, reduce the temperature before testing again.*
2. Upon completion of the output current test, lower the engine speed to idle and turn off the ignition switch.
3. Disconnect the battery ground cable.
4. Remove the ammeter and voltmeter and the engine tachometer.
5. Connect the generator output wire to the generator "B" terminal.
6. Connect the battery ground cable.

REGULATED VOLTAGE TEST


EBDA0330

The purpose of this test is to check that the electronic voltage regulator controls the voltage correctly.

PREPARATION

1. Prior to the test, check the following items and correct if necessary.
 - 1) Check that the battery installed in the vehicle is fully charged. For battery checking method, see the "BATTERY" section.
 - 2) Check the generator drive belt tension. For belt tension check, see section, "COOLING."

2. Turn ignition switch to "OFF."
3. Disconnect the battery ground cable.
4. Connect a digital voltmeter between the "S(L)" terminal of the generator and ground. Connect the (+) lead of the voltmeter to the "S(L)" terminal of the generator. Connect the (-) lead to a good ground or the battery (-) terminal.
5. Disconnect the generator output wire from the generator "B" terminal.
6. Connect a DC ammeter (0 to 100A) in series between the "B" terminal and the disconnected output wire. Connect the (-) lead wire of the ammeter to the disconnected output wire.
7. Attach the engine tachometer and connect the battery ground cable.



EBDA033A

TEST

1. Turn on the ignition switch and check to see that the voltmeter indicates the following value.
Voltage : Battery voltage
If it reads 0V, there is an open circuit in the wire between the generator "S(L)" terminal and the battery and the battery (+), or the fusible link is blown.
2. Start the engine. Keep all lights and accessories off.
3. Run the engine at a speed of about 2,500 rpm and read the voltmeter when the generator output current drops to 10A or less.

RESULT

1. If the voltmeter reading agrees with the value listed in the Regulating Voltage Table below, the voltage regulator is functioning correctly. If the reading is other than the standard value, the voltage regulator or the generator is faulty.

REGULATING VOLTAGE TABLE

Voltage regulator ambient temperature °C(°F)	Regulating voltage V	
	75A generator	90A generator
-20 (-4)	14.2-15.4	14.3-15.2
20 (68)	13.9-14.9	14.1-14.7
60 (140)	13.4-14.6	13.5-14.4
80 (176)	13.1-14.5	13.3-14.3


2. Upon completion of the test, reduce the engine speed to idle, and turn off the ignition switch.
3. Disconnect the battery ground cable.
4. Remove the voltmeter, ammeter, and the engine tachometer.
5. Connect the generator output wire to the generator "B" terminal.
6. Reconnect the battery ground cable.

GENERATOR


EBNC0350

COMPONENTS

75A




90A



TORQUE : Nm (kg.cm, lb.ft)


REMOVAL EBNC0360

1. Disconnect the negative(-) terminal from the battery and disconnect the radiator fan connector and condenser fan connector.




EBDA035B

2. Remove the radiator mounting bolts




EBDA035C

3. Loosen the belt tension adjusting bolt and remove the mounting bolt.
Then, raise the vehicle.




EBDA035D

4. Disconnect the generator connector and remove the B+ terminal cable.



EBDA035E

5. Remove the belt and detach the generator mounting bolt and nut.
Then, remove the generator assembly while raising the radiator.




EBDA035F


COMPONENTS

EBNC0370

<75A>



<90A>



1. Pulley	9. Plate
2. Seal	10. Voltage regulator and brush holder
3. Rotor assembly	11. Brush
4. Rear bearing	12. Brush spring
5. Bearing retainer	13. Slinger
6. Front bearing	14. Rectifier
7. Front bracket	15. Rear bracket
8. Stator	


DISASSEMBLY (75A)

EBNC0380


1. Remove the three through bolts.
2. Insert a flat screwdriver between the front bracket and stator core, and pry downward.

CAUTION

1. *Do not insert the screwdriver too deeply, as there is a danger of damaging the stator coil.*
2. *The rear cover may be hard to remove because a ring is used to lock the outer race of the rear bearing. To facilitate removal of the rear cover, heat the bearing box section with a 200-watt soldering iron.*
Do not use a heat gun, as it may damage the diode assembly.



EBDA037B



EBDA037C

3. Secure the rotor in a vise with the pulley side up.

CAUTION

Be careful that the vise jaws do not damage the rotor.


4. Remove the pulley nut, then remove the spring washer, then the pulley, and then the spacer.
5. Remove the front bracket and two seals.
6. Remove the rotor from the vise.
7. Remove the brush holder screws, rectifier screws, and nut from the B terminal.

8. Remove the stator assembly from the rear bracket.
9. Detach the slinger from the brush holder.
10. When the stator is to be removed, unsolder the three stator leads to the main diodes on the rectifier.


CAUTION

1. *When soldering or unsoldering, be careful not to heat the diodes for too long.*
2. *Be careful that excessive force is not exerted on the leads of the diodes.*

11. When separating the rectifier from the brush holder, unsolder the two plates that are soldered to the rectifier



EBDA037D



EBDA037E


INSPECTION (75A)

EBDA0390

ROTOR


1. Check the rotor coil for continuity. Check to make sure that there is continuity between the slip rings. If resistance is extremely low, it means that there is a short. If there is no continuity or if there is a short circuit, replace the rotor assembly.

Resistance value : Approx. 3.1Ω



EBDA039A

2. Check the rotor coil for ground. Check to make sure that there is no continuity between the slip ring and the core. If there is continuity, replace the rotor assembly.




EBDA039B

STATOR


1. Make a continuity check on the stator coil. Check to make sure that there is continuity between the coil leads.

If there is no continuity, replace the stator assembly.



EBDA039C

2. Check the coil for grounding. Check to make sure that there is no continuity between the coil and the core. If there is continuity, replace the stator assembly.




EBDA039D

RECTIFIERS

POSITIVE RECTIFIER TEST

Check for continuity between the positive rectifier and stator coil lead connection terminal with an ohmmeter. The ohmmeter should read continuity in only one direction. If there is continuity in both directions, a diode is shorted.


Replace the rectifier assembly.



EBDA039E

NEGATIVE RECTIFIER TEST

Check for continuity between the negative rectifier and the stator coil lead connection terminal. The ohmmeter should read continuity in only one direction. If there is continuity in both directions, a diode is shorted, and the rectifier assembly must be replaced.




EBDA039F


DIODE TRIO TEST

Check the three diodes for continuity by connecting an ohmmeter to both ends of each diode. Each diode should have continuity in only one direction.

If continuity is present in both directions, a diode is defective and the heatsink assembly must be replaced.




EBDA039G



EBDA039J


BRUSH REPLACEMENT

Replace the brushes if they are worn to the limit line.




EBDA039H

1. Unsolder the pigtail and remove the old brush and spring.



EBDA039I

2. Install the brush spring and a new brush in the brush holder.
3. Insert the brush so that there is a space of 2 to 3 mm (0.079 to 0.118 in.) between the limit line and the end of the brush holder.
4. Solder the pigtail to the brush holder.




EBDA041A

3. Remove the stator assembly from the rear bracket.
4. Remove the brush holder and the rectifier.
5. Remove the four through bolts.
6. Insert a flat screwdriver between the front bracket and stator core, and pry downward.




NOTE


1. Do not insert the screwdriver too deeply, as there is a danger of damaging the stator coil.
2. The rear cover may be hard to remove because a ring is used to lock the outer race of the rear bearing. To facilitate removal of the rear cover, heat just the bearing box section with a 200-watt soldering iron. Do not use a heat gun, as it may damage the diode assembly.



EBDA041B



EBDA041E



EBDA041C

INSPECTION (90A) EBDA0430

ROTOR

1. Check the rotor coil for continuity. Check to make sure that there is continuity between the slip rings. If resistance is extremely low, it means that there is a short. If there is no continuity or if there is a short circuit, replace the rotor assembly.


Resistance value : Approx. 3.1Ω

7. Secure the rotor in a vise with the pulley side up.


NOTE

Be careful that the vise jaws do not damage the rotor.

8. Remove the pulley nut, then remove the spring washer, then the pulley, and then the spacer.
9. Remove the front bracket and seals.
10. Remove the rotor from the vise.




EBDA041D



EBDA043A

2. Check the rotor coil for ground. Check to make sure that there is no continuity between the slip ring and the core. If there is continuity, replace the rotor assembly.




EBDA043B


11. When separating the rectifier from the brush holder, unsolder the two plates soldered to the rectifier.

STATOR

1. Make a continuity check on the stator coil. Check to make sure that there is continuity between the coil leads. If there is no continuity, replace the stator assembly.




EBDA043C



EBDA043F

2. Check the coil for grounding. Check to make sure that there is no continuity between the coil and the core. If there is continuity, replace the stator assembly.




EBDA043D

RECTIFIERS

POSITIVE RECTIFIER TEST

Check for continuity between the positive rectifier and stator coil lead connection terminal with an ohmmeter. The ohmmeter should read continuity in only one direction. If there is continuity in both directions, a diode is shorted.



EBDA043E


NEGATIVE RECTIFIER TEST

Check for continuity between the negative rectifier and the stator coil lead connection terminal. The ohmmeter should read continuity in only one direction. If there is continuity in both directions, a diode is shorted, and the rectifier assembly must be replaced.

DIODE TRIO TEST

Check the three diodes for continuity by connecting an ohmmeter to both ends of each diode. Each diode should have continuity in only one direction.

If continuity is present in both directions, a diode is defective and the heatsink assembly must be replaced.



EBDA043G


REASSEMBLY

EBDA0450


Reassembly is the reverse procedure of disassembly. Pay attention to the following:

Before the rotor is attached to the rear bracket, insert a wire through the small hole in the rear bracket to lock the brush. After the rotor has been installed, the wire can be removed.


<75A>



EBDA045A



EBDA045B




EBDA049A

INSTALLATION

EBDA0470

1. Position the generator and insert the support bolt. (Do not attach the nut.)
2. Push the generator forward and determine how many spacers (thickness : 0.198mm) should be inserted between the front leg of the generator and the front case (space "A" in the illustration).
(There should be enough spacers so that they do not fall out when you let go of them.)
3. Insert the spacers (space "A" in the illustration), attach the nut, and complete the installation.




EBDA047A


BATTERY

EBDA0490


1. The maintenance-free battery is, as the name implies, totally maintenance free and has no removable battery cell caps.
2. Water never needs to be added to the maintenance-free battery.
3. The battery is completely sealed, except for small vent holes in the cover.

BATTERY VISUAL INSPECTION (1)





EBDA049D



EBDA049E

SPECIFIC GRAVITY CHECK CHART

EBDA0510

The specific gravity of battery electrolyte changes with temperature. Heat thins the solution and lowers the specific gravity. Cold thickens the solution and raises the specific gravity.

A fully charged battery should have a specific gravity between 1.260 and 1.280, with the electrolyte temperature at 26.7°C. The specific gravity reading must be corrected by adding 4 points (.004) for each 5.56°C above 26.7°C or subtracting 4 points for every 5.56°C below 26.7°C.

For example : The hydrometer reading is 1.280, and the electrolyte temperature reading is 5.56°C. According to the chart below, the specific gravity must be lowered by 0.028 points. The true corrected reading is 1.252.

$$1.280 - 0.028 = 1.252$$


You should never take a hydrometer reading immediately after water has been added. The water and electrolyte must be mixed by either charging for a few minutes at a low rate or by allowing the battery to sit for an hour.

CAUTION

A difference of 50 points (0.050) or more between one or more cells indicates a defective battery. It should be replaced.

ELECTROLYTE
TEMPERATURE

SPECIFIC GRAVITY
CORRECTION



EBDA051A

BATTERY CHARGE RATE

EBDA0530

Specific gravity	Charge method	
	Slow charge (5A)	Fast charge (20A)
Below 1.100	14 hours	4 hours
100 - 1.130	12 hours	3 hours
130 - 1.160	10 hours	2.5 hours
160 - 1.190	8 hours	2.0 hours
190 - 1.220	6 hours	1.5 hours
Above 1.220	4 hours	1.0 hour


BATTERY VISUAL INSPECTION (2)

EBDA0550

1. Make sure ignition switch is in the Off position and all accessories are Off.
2. Disconnect the battery cables (negative first).
3. Remove the battery from the vehicle.

CAUTION

Care should be taken in the event that the battery case is cracked or leaking, to protect your skin from the electrolyte. A suitable pair of rubber gloves (not household type) should be worn when removing the battery.




EBDA055A

4. Inspect the battery carrier for damage caused by the loss of acid from the battery. If acid damage is present, it will be necessary to clean the area with a solution of clean, warm water and baking soda. Scrub the area with a stiff brush and wipe off with a cloth moistened with baking soda and water.
5. Clean the top of the battery with the same solution as described in step 4.
6. Inspect the battery case, and cover, for cracks. If cracks are present, the battery must be replaced.
7. Clean the battery posts with a suitable battery post cleaner.

8. Clean the inside surface of the terminal clamps with a suitable battery terminal cleaning tool. Replace damaged or frayed cables and broken terminal clamps.
9. Install the battery in the vehicle.
10. Connect the cable terminals to the battery post, making sure the top of the terminals are flush with the top of the post.
11. Tighten the terminal nut securely.
12. Coat all connections with light mineral grease after tightening.

CAUTION

When batteries are being charged, an explosive gas forms beneath the cover of each cell. Do not smoke near batteries being charged or which have recently been charged. Do not break live circuits at the terminals of the batteries being charged. A spark will occur where the circuit is broken. Keep all flames away from an open battery.



EBDA055B

STARTING SYSTEM


GENERAL INFORMATION

EBDA0570

The starting system includes the battery, starter motor, solenoid switch, ignition switch, inhibitor switch (A/T only), connection wires and the battery cables.

When the ignition key is turned to the start position, current flows and energizes the starter motor's solenoid coil. The solenoid plunger and clutch shift lever are activated, and the clutch pinion engages the ring gear. The contacts close and the starter motor cranks.

In order to prevent damage caused by excessive rotation of the starter armature when the engine starts, the clutch pinion gear overruns.




EBDA057A

TROUBLESHOOTING


Trouble condition	Probable cause	Remedy
Engine will not crank	Battery charge low Battery cables loose, corroded or worn Transaxle range switch faulty (Vehicle with automatic transaxle only) Fusible link blown Starter motor faulty Ignition switch faulty	Charge or replace battery Repair or replace cables Adjust or replace switch Replace fusible link Repair starter motor Replace ignition switch
Engine cranks slowly	Battery charge low Battery cables loose, corroded or worn Starter motor faulty	Charge or replace battery Inspect wiring and fix Repair starter motor
Starter keeps running	Starter motor faulty Ignition wiring faulty	Repair starter motor Repair or replace
Starter spins but engine will not crank	Short in wiring Pinion gear teeth broken or starter motor faulty Ring gear teeth broken	Repair wiring Repair starter motor Replace flywheel ring gear or torque converter

CIRCUIT DIAGRAM FOR STARTING SYSTEM



COMPONENT

EBNC0590

**TORQUE : Nm (kg·cm, lb·ft)**

EBDA059A


REMOVAL

EBNC0600

1. Disconnect the battery ground cable.
2. Remove the speedometer cable and the shift cable.
3. Disconnect the starter motor connector and terminal.
4. Remove the starter motor assembly.
5. Installation is the reverse order of removal.

COMPONENTS

EBNC0610



1. Front bracket
 2. Front bushing
 3. Cap
 4. Screw
 5. Solenoid
 6. Plunger
 7. Spring
 8. Packing

9. Lever
 10. Holder
 11. Spring
 12. Packing
 13. Washer
 14. Stop ring
 15. Stopper
 16. ORC

(Overrunning clutch)


17. Armature
 18. Washer
 19. Yoke ass'y
 20. Plate ass'y
 21. Rear cover
 22. Rear bushing
 23. Screw
 24. Bolt

ADJUSTMENT EBNC0620**PINION GAP**

1. Disconnect the wire from the M-terminal.
2. Connect a 12V battery between the S-terminal and the M-terminal.
3. Set the switch to "ON", and the pinion will move out.

CAUTION


This test must be performed quickly (in less than 10 seconds) to prevent the coil from burning.



EBDA061B

4. Check the pinion to stopper clearance (pinion gap) with a feeler gauge. If the pinion gap is out of specification, adjust by adding or removing washers between the solenoid and the front bracket.

PINION GAP : 0.5–2.0 mm (0.0197–0.079 in.)



EBDA061C


SOLENOID PULL-IN TEST

1. Disconnect the connector from the M-terminal.
2. Connect a 12V battery between the S-terminal and M-terminal.

CAUTION

This test must be performed quickly (in less than 10 seconds) to prevent the coil from burning.

3. If the pinion moves out, the pull-in coil is good. If it doesn't, replace the solenoid.



EBDA061D


SOLENOID HOLD-IN TEST

1. Disconnect the connector from the M-terminal.
2. Connect a 12V battery between the S-terminal and the body.

CAUTION

This test must be performed quickly (in less than 10 seconds) to prevent the coil from burning.

3. If the pinion remains out, everything is in order. If the pinion moves in, the hold-in circuit is open. Replace the magnetic switch.



EBDA061E


SOLENOID RETURN TEST

1. Disconnect the connector from the M-terminal.
2. Connect a 12V battery between the M-terminal and the body.

CAUTION

This test must be performed quickly (in less than 10 seconds) to prevent the coil from burning.


3. Pull out the pinion and then release it. If the pinion returns quickly to its original position, everything is in order. If it doesn't, replace the solenoid.



EBDA061F

PERFORMANCE TEST (NO-LOAD)

1. Make the no-load circuit test as shown.
2. After adjusting the rheostat until the battery voltage shown on the voltmeter reads 11.5 volts, confirm that the maximum amperage draw is within the specifications and that the starter motor turns smoothly and freely.

CURRENT : 60A or less


EBDA061G

DISASSEMBLY

EBDA0630

To remove the overrunning clutch from the armature shaft, the stop ring must be removed.

Move the stop ring toward the pinion and remove the snap ring. Now the stop ring can be removed from the shaft.




EBDA063A

INSPECTION (AFTER DISASSEMBLY)

EBDA0650

ARMATURE COIL GROUND TEST


Using an ohmmeter, check to make sure that there is no continuity between the commutator and the armature coil core. If there is continuity, replace the armature assembly.



EBDA065A

ARMATURE COIL SHORT-CIRCUIT TEST


Test the armature coil in a growler. Replace the coil if there are signs of a short. If the blade attached to the core vibrates while the core is turned, the armature is shorted.



EBDA065B

ARMATURE COIL OPEN-CIRCUIT TEST


Using an ohmmeter, check for continuity between the commutator segments. If there is no continuity, the commutator segments are open. Replace the armature assembly.




EBDA065C

FIELD COIL OPEN-CIRCUIT TEST

Using an ohmmeter, check the field coil for continuity. If there is no continuity, the field coil is open. Replace the field coil assembly.




EBDA065D



EBDA065G

FIELD COIL GROUND TEST


With the field coil mounted to the yoke, check for continuity between the field coil and the yoke using an ohmmeter. If there is continuity, replace the field coil.




EBDA065E

BRUSH

A brush worn down to the wear limit line should be replaced.




EBDA065F



EBDA065H

BRUSH REPLACEMENT

1. Remove the worn brush while taking care not to damage the pigtail.
2. Sand the pigtail end with sandpaper to ensure a good soldering joint.
3. Solder the end of the pigtail.



EBDA065I


BRUSH HOLDER

Check for continuity between the (+) side brush holder and brush holder base. If there is continuity, replace the holder assembly.

REAR BRACKET BUSHING REPLACEMENT

1. Before the bushing is removed, measure and record the pressed-in position (depth) of the bushing.

2. The bushing can be removed by the use of a puller as shown in the illustration.
3. Press a new bushing in, up to the position recorded under Step. 1.




EBDA065J

REASSEMBLY


EBDA0670

1. Install the overrunning clutch to the front end of the armature shaft.
2. Install the stop ring and the snap ring from the front end of the armature shaft. Push the stop ring all the way toward the snap ring.



EBDA067A

3. When the lever is mounted on the front bracket, pay attention to its direction. If it is mounted in a reverse direction, the pinion will remain in an outward position and fail to operate properly.




EBDA067B

**INSPECTION OF CLUTCH START SYSTEM
(IGNITION LOCK SYSTEM)**

EBDA0690

CHECK CLUTCH PEDAL

Check that pedal height, pedal freeplay and clutch pedal clevis pin play are correct. (Refer to CH group)



EBDA069A


CHECK STARTER RELAY

EBDA0710

Remove the starter relay and check continuity between the terminals. If the continuity is not as specified, replace the relay.

Condition	Terminal	S1 ⁽¹⁾	S2 ⁽³⁾	L ⁽²⁾	B ⁽⁴⁾
When de-energized		<input type="checkbox"/>	<input type="checkbox"/>		
When energized		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

EBDA071B




EBDA071A

CHECK IGNITION LOCK SWITCH EBDA0730

Check for continuity between terminals.

Condition	Terminal	1	2
Pushed		○	—
Free		—	—

EBDA073B



EBDA073A