



Glove Box Light

Test


1. Open the glove box.
2. Disconnect the 2P connector from the light.
3. There should be continuity between the \oplus and \ominus terminals with a bulb installed.





Trunk Light


Test

1. Pry off the trunk light lens from the housing.
2. Pry off the light assembly.
3. Disconnect the connectors from the housing.



4. Make sure that the bulb, is in good condition. Set the trunk light switch in the ON position and check for continuity between terminals.






Latch Switch

Test/Replacement

1. Open the trunk lid.
2. Disconnect the connector from the trunk latch.
3. There should be continuity between the A terminal and body ground.



4. If necessary, remove the 3 bolts to pull out the latch from the trunk lid, then disconnect the lock rod from the latch.

