



# Overhaul

**NOTE:**

- Before reassembly, make sure that the air door and linkage move smoothly without binding.
- **RECIRCULATION CONTROL CABLE ADJUSTMENT**  
Side the recirculation control lever to "RECIRC". Then connect the control cable to the arm while holding the air doors shut.

