

Driveshafts

Disassembly/Inspection

NOTE:

- Mark the rollers and roller grooves during disassembly to ensure proper positioning during reassembly.
- Before disassembly, mark the spider and driveshaft so they can be reinstalled in their original positions.
- The inboard joint must be removed to replace the boots.

GREASE Grease is used on the inside surface of the joint boots. Do not mix the two joint boot. The type of grease used on each boot is different.

Grease Quantity:

	L. Driveshaft	R. Driveshaft
Inboard Joint	120~130g	120~130g
Outboard Joint	90~100g	90~100g

