


Maintenance - Transmission

MANUAL GEARBOX OIL

Oil level check

1. Raise vehicle on a ramp.
2. Clean area around filler/level plug.




8RM 3872

3. Remove filler/level plug.
4. Check oil level and top - up if necessary to bottom of filler/level plug hole with oil of correct specification.
5. Fit filler/level plug and tighten to 45 Nm.
6. Lower ramp.

Drain and refill

1. Raise vehicle on a ramp.
2. Clean area around drain plug.
3. Position container beneath gearbox.



8RM 3873

4. Remove drain plug, allow oil to drain; discard oil drained from gearbox.
5. Fit drain plug and tighten to 40 Nm.
6. Remove filler/level plug.
7. Fill gearbox with oil of correct specification until level reaches bottom of filler/level plug hole.
8. Fit filler/level plug and tighten to 45 Nm.
9. Lower ramp.