


# Taillights Assembly

## Replacement

1. Open the trunk lid and remove the trunk side panel.
2. Disconnect the 4-P connector from behind the taillight.
3. Remove the 4 mounting nuts and the taillight assembly.




4. Inspect the gasket; replace if it is distorted or overly compressed.

# Rear Panel Lights Assembly



## Replacement

1. Open the trunk lid and remove the rear trim cover.
2. Disconnect the 4-P connectors from behind the rear panel lights.
3. Remove the 8 mounting nuts and the rear panel lights assembly.



4. Inspect the gasket; replace if it is distorted or overly compressed.