


Rear Suspension


Hub Unit Bearing Replacement

Disc Brake:

1. Pry nut lock tab away from spindle, then loosen nut using 32 mm socket and breaker bar.



2. Loosen the wheel nuts slightly.
 3. Jack up the rear of car and support on safty stands in proper location.
 4. Remove the wheel nuts, wheel, and spindle nut.
 5. Remove the caliper shield.
 6. Remove the caliper mounting bolts and hang the caliper assembly to one side.
- CAUTION:** To prevent accidental damage to the caliper assembly or brake hose, use a short piece of wire to hang the caliper assembly from the under carriage.
7. Remove the brake disc retaining screws and brake disc.
 8. Remove the hub unit and hub unit bearing.



Drum Brake:

1. Jack up the rear of car and support on safety stands in proper location.
2. Remove the rear wheel and brake drum.
3. Remove the hub unit cap, unstake the spindle nut, then loosen the spindle nut.
4. Remove the hub unit and hub unit bearing.

