

# Timing Belt

## Illustrated Index



**NOTE :**

- Refer to page 5-31 for positioning crank and pulley before installing belt.
- Refer to page 5-10, for alternator belt adjustment.
- Refer to page 5-11, for A/C compressor belt adjustment.
- Refer to page 5-12, for P/S pump belt adjustment.
- Before removing the timing belt, mark direction of rotation.

**TIMING BELT**

Inspection, page 5-28  
 Adjustment, page 5-28  
 Replace every 100,000 km  
 (60,000 miles) or 60 months.

