


## Inspection


Inspect the steering pump for leak or damage.  
Turn the pulley and check that the pump shaft turns smoothly.



## Pulley Replacement

Hold the pulley in a vise with soft jaws, and remove the three pulley bolt, then remove the pulley.

**CAUTION:** Do not try to disassemble the pump. If the pump is faulty, replace the whole pump as an assembly.



**PULLEY BOLT**  
10 N·m  
(1.0 kg-m, 7 lb-ft)