

Fuel system



20. Adjust fuel injection pump timing, see **Adjustments**.
21. Fit starter motor, see **ELECTRICAL - Repairs**.
22. Position rear portion of timing belt cover to backplate, bottom cover and locating pegs; fasten clips.
23. Position front portion of timing belt cover to backplate and locating pegs; fasten clip.

Turbo Models

24. Connect hoses to intercooler and intercooler adaptor.
25. Connect hoses to air box; tighten clips.

All Models

26. Raise engine, position engine R.H. mounting bracket; fit securing nuts and tighten to 50 Nm.
27. Remove trolley jack.
28. Remove stand(s) and lower vehicle.
29. Check/adjust engine idle speed, see **Adjustments**.




8RM 4034

FAST IDLE SENSOR

Remove


1. Drain cooling system, see **MAINTENANCE**.



8RM 4033


2. Slacken clip, disconnect breather hose from oil filler tube.

3. Release hose from clip on air cleaner; move hose aside.
4. Slacken clip, disconnect hose from air cleaner.
5. Slacken clip, disconnect hose from air box; remove hose.




8RM 4035

6. **Turbo Models:** Slacken 2 clips, disconnect hose from air box and intercooler adaptor.



All Models

7. Slacken nut securing fast idle cable stop.
8. Remove stop from fast idle cable, withdraw cable from lever.
9. Remove adjusting nut from fast idle outer cable; withdraw cables from abutment bracket.



10. Using a 30 mm spanner, remove fast idle sensor.

Refit

1. Clean all traces of silicone sealant from threads of thermostat housing.
2. Coat threads of fast idle sensor with silicone sealant.
3. Fit fast idle sensor and tighten using a 30 mm spanner.
4. Locate inner and outer cables in hole in abutment bracket; fit and tighten adjusting nut.
5. Locate fast idle inner cable in hole in lever.
6. Locate cable stop on fast idle inner cable and position stop 0.5 to 1.0 mm from lever; tighten cable stop securing nut.

Note: If correct clearance between inner cable stop and lever cannot be obtained, slacken outer cable locknut and adjust length of outer cable by means of adjusting nut until correct clearance is obtained; tighten locknut.

7. Turbo Models: Connect hose to air box and intercooler; tighten clips.

All Models

8. Connect hose to air cleaner and air box; tighten clips.
9. Secure hose in clip on air cleaner.
10. Connect breather hose to oil filler tube; tighten clip.
11. Refill cooling system, see **MAINTENANCE**.