


Lubrication Points


No.	LUBRICATION POINTS	LUBRICANT
1	Engine	API Service Grade: SE, SF or SG SAE Viscosity : See chart below
2	Transmission Manual Automatic	API Service Grade: SE or SF SAE Viscosity: See chart below DEXRON® or DEXRON®II Automatic transmission fluid
3	Brake line (ALB Line for ALB models)	Brake fluid DOT 3 or DOT4
4	Power steering system	Honda power steering fluid P/N. 08208-99961
5	Steering gearbox	Honda steering grease P/N. 08733-B070E
6	Shift lever pivot (Manual transmission)	Silicone grease with molybdenum disulfide
7	Steering ball joints	Multi-purpose grease
8	Suspension ball joints	
9	Steering boots	
10	Tilt steering	
11	Steering column bushdngs	
12	Select lever (Automatic transmission)	
13	Pedal linkage	
14	Brake master cylinder push rod	
15	Tailgate hinges or trunk hinges	
16	Door hinges upper and lower	
17	Door opening detents	
18	Fuel filler lid	
19	Engine hood hinges	
20	Engine hood latch	
21	Caliper Piston seal Dust seal Caliper pin Piston	Silicone grease

Recommended Engine Oil
(SE, SF or SG Grade oil)



Engine oil viscosity for
ambient temperature ranges

Recommended Manual Transmission Oil
(SE or SF Grade oil)



Transmission oil viscosity for
ambient temperature ranges

CAUTION: Used engine oil may cause skin cancer if repeatedly left in contact with the skin for prolonged periods. Although this is unlikely unless you handle used oil on a daily basis, it is still advisable to thoroughly wash your hands with soap and water as soon as possible after handling used oil.

