


Cigarette Lighter

Component Location Index




- **CIGARETTE LIGHTER**
Test, page 16-128
Replacement, page 16-129



CIGARETTE LIGHTER RELAY
[Wire colors: BLU/SLT, BLK, BLU/GRN and pup]
Test, page 16-129


Cigarette Lighter

Circuit Diagram



Test

1. Remove the center instrument panel, then disconnect the 4-P connector from the cigarette lighter.
2. Check for voltage between the BLU/SLT and the BLK terminal.
There should be battery voltage.
 - If there is no voltage, check for
 - Blown No.12 (15A) or No.17 (10A) fuse in the dash fuse box.
 - An open in the Pup or BLU/SLT wire.
 - Faulty cigarette lighter relay. (Test, page 16-)
 - If there is battery voltage, replace the cigarette lighter assy.






Replacement

1. Remove the center instrument panel, then disconnect the 4-P connector from the cigarette lighter.
2. Disconnect the thermofuse case from the socket end.
3. Remove the ring nut and separate the cigarette lighter socket.

NOTE: When installing the cigarette lighter, align the lug on the cigarette lighter socket with the slot in the panel.



Cigarette Lighter Relay Test

There should be continuity between the A and B terminals when the battery is connected to the C and D terminals. There should be no continuity when the battery is disconnected.

