




Interior Light (With Security Alarm System)

Test/Replacement

NOTE:



- When replacing the bulb, only take the lens off from the housing, and replace it.
- To test the infra-red signal receiving sensor, see page 16-15.

1. Turn the switch OFF.
2. Pry off the lens.
3. Remove the two nuts and disconnect the 4-P connector, then remove the housing.



4. Check for continuity between the terminals in each switch position according to the table.

Terminal	A		B	C
Position				
OFF				
MIDDLE	○	⊕	○	
ON	○	⊕		○



- If the interior light fails to operate properly, replace it.