




Positive Crankcase Ventilation

PCV Valve Test

1. Check the crankcase ventilation hoses and connections for leaks and clogging.



2. At idle, make sure there is a clicking sound from the PCV valve when you lightly pinch the PCV hose with your fingers or pliers.
 - If no clicking sound is heard, replace PCV valve and recheck.

Blow-by Filter Test

Inspect the condition of the blow-by filter.

- Replace the filter in the following instances:
 - When the filter is stuck fast and oil is dripping or seeping through.
 - When the filter is covered with dust and dirt so that clogging is evident.

