




Dash Fuse Box

NOTE: Dash fuse box is located right side, under dash.



* : SPAER FUSE
 ● : Not used

