



Component Location

Index

The power steering is rack and pinion type. The power operating assembly is integral with the steering gear. Road feel is maintained throughout the entire speed range of the vehicle.

NOTE: RH Drive shown, LH Drive is similar.

IGNITION SWITCH

Steering Lock Replacement and Switch Test, see Electrical Section.

STEERING WHEEL

Steering wheel positioning, see Suspension/Alignment Disassembly/Reassembly, page 11-32

COLUMN

Removal, page 11-33
Disassembly/Inspection, page 11-35
Reassembly, page 11-36
Installation, page 11-38

STEERING GEARBOX

Index, page 11-43
Removal, page 11-44
Installation, page 11-46

TIE ROD END

See Suspension Section.

RESERVOIR

PUMP

Pump Belt Adjustment, page 11-29
Fluid Replacement, page 11-30
Pump Pressure Check, page 11-30
Pump Replacement, page 11-41
Inspection, page 11-42

