

# Air Conditioner

- Illustrated Index ..... 15-19
- Circuit Diagram ..... 15-20
- Service Tips ..... 15-22
- Torque Specifications ..... 15-23
- Wire Harness Routing ..... 15-24
- Troubleshooting
  - Symptom Chart ..... 15-25
  - Flow Chart ..... 15-26
- Discharge Procedure ..... 15-36
- Condenser Replacement ..... 15-37
- Evaporator
  - Replacement ..... 15-38
  - Overhaul ..... 15-39
- Compressor
  - Description ..... 15-40
  - Replacement ..... 15-41
  - Clutch Inspection ..... 15-44
  - Clutch Overhaul ..... 15-45
  - Thermal Protector Inspection ... 15-47
  - Thermal Protector Replacement 15-47
  - Shaft Seal Replacement ..... 15-48

- System Charging
  - System Evacuation ..... 15-50
  - Leak Test ..... 15-51
  - Charging Procedure ..... 15-52
  - Supplement ..... 15-53
- Test
  - Thermo Switch ..... 15-54
  - Relay ..... 15-54
  - A/C Switch ..... 15-55
  - Diode ..... 15-55
  - Performance Test ..... 15-56
  - Idle Speed Setting ..... 15-57

## Special Tools

Ref. No.	Tool Number.	Description	Q'ty	Page Reference
①	07HAF-SF10300	SHAFT SEAL REMOVER	1	15-48
②	07HAF-SF10400	SEAL REMOVER/INSTALLER	1	15-48,49

