



Release Bearing

Removal


1. Remove the 8 mm special bolt.
2. Remove the release shaft and release bearing assembly.



3. Separate the release fork from the bearing by removing the release fork spring from the holes in the release bearing.



4. Check the release bearing for excessive play by spinning it by hand.




5. Replace the bearing with a new one if there is excessive play.

CAUTION : The bearing is packed with grease. Do not wash it in solvent.

Release Bearing


Installation

1. Install the release fork spring in the locating holes as shown.




2. Align the release fork with the locating holes of the release bearing.


RELEASE FORK SPRING RELEASE FORK



3. Install the release shaft and the release bearing.
NOTE: Apply molybdenum disulfide grease to the release shaft.



4. Align the release shaft and release fork, then install a new spring washer and bolt.



5. Move the release fork up and down to make sure the fork fits properly against the bearing, and that the bearing slides freely.