



Clock

Removal

1. Remove the upper trim panel from the instrument panel, then carefully pull out the 10 clips.
2. Disconnect the 4-P connector from the clock.
3. Remove the 2 screws and clock from the panel.



Terminals



Terminal	Wire	Destination
A	WHT/BLU	Constant power (Time memory)
B	YEL	IG1 (Main clock power supply)
C	RED/BLK	Light-on signal
D	BLK	Ground