





Electrical Connections [1.5 l]

FUSES

- ① ECU (15A)*
- ② No. 14 (10A)
- ③ No. 2 (10A)

- ④ No. 12 (15A)
- ⑤ HAZARD (10A)*

* : In the main fuse box




TERMINAL LOCATION

System Description

Electrical Connections [1.6 l with CATA]

FUSES

- ① ECU (15A)*
 - ② No. 14 (10A)
 - ③ No. 2 (10A)
 - ④ No. 12 (15A)
 - ⑤ HAZARD (10A)*
- * : In the main fuse box







Electrical Connections [1.6 l without CATA]

FUSES

- ① ECU (15A)* ④ No. 12 (15A)
- ② No. 14 (10A) ⑤ HAZARD (10A)*
- ③ No. 2 (10A) * : In the main fuse box



TERMINAL LOCATION