


Evaporator

Replacement


1. Disconnect the battery negative terminal.
2. Discharge the refrigerant (page 15-36).
3. Disconnect the receiver line and suction hose from the evaporator.

CAUTION: Cap the open fittings immediately to keep moisture out of the system.




4. Remove the glove box.
5. Disconnect the connector from the A/C thermostat pull off the wire harness from the clamps.

6. Remove the tapping screws (2) and A/C bands.



7. Remove the mounting bolts (2) and evaporator.



8. Install in the reverse order of removal, and:

- Apply a sealant to the grommets.
- Make sure that there is no air leakage.
- Charge the system (page 15-50) and test performance (page 15-56).