





# Rear Door

## Disassembly


1. Remove the inside handle trim plate and regulator handle (page 14-4).
2. Remove the screws and clips (See door panel release tool) attaching the door panel (page 14-4). Remove the door panel by pulling it upward and disconnect the power window and courtesy light wires.



3. Remove the screws, then remove the door panel brackets.
4. Carefully remove the plastic cover.




5. Remove the 3 screws of the inside door handle and the screw of the lock crank, then remove it from the door.



6. Reconnect the window switch or use 12 V battery to operate the window regulator.
7. Raise the window fully.
8. Pull the outside door handle out, and pry the joint with a flat tip screwdriver. Remove the handle from the rod.

NOTE: Use protective tape around the edge of the outside door handle to prevent scratching the paint.



(cont'd)


# Rear Door

## Disassembly (cont'd)


9. Remove the screws and disconnect the latch rod and wire.
10. Take the latch assembly off the door, then push the latch assembly inside the door.

**NOTE:**

- Remove the lower bolt of the rear channel and slide the rear channel.
- Take care not to bend the latch rods.



11. Carefully lower the door glass until you can see its mounting bolts.
12. Remove the outside and inside cover panels.
13. Remove the glass run channel and rear channel.
14. Use protective tape as shown to prevent scratching the paint.







# Doors

## Molding Replacement


16. Stand next to the outside of the door, tilt the glass as shown, and pull it out through the window opening.



17. Remove the 4 mounting bolts and loosen the 2 motor bolts, then take out the regulator assembly through the lower hole in the door.




18. Remove the nut, then remove the center channel.





### Outer Molding:

1. Lower the window fully.
2. Remove the door mirror (pages 14-13, 14).
3. Remove the screw and detach the clips, then remove the outer molding prying up on the molding starting at the rear.




OUTER MOLDING



CLIP DOOR

MOUNTING SCREW



OUTER MOLDING

(cont'd)