

Electronic Components

Control Unit Replacement


CAUTION:

- Disconnect the battery ground terminal before remove the control unit.
- The memory of the problem code is erased, if disconnect the battery ground terminal.

Remove the control unit attaching nuts, then remove the control unit.

CAUTION:

- Handle the control unit with care.



Installation is the reverse order of removal.

NOTE: Check the dash warning light function by turning the ignition switch ON.

Fail Safe Relays/Motor Relay Inspection

1. Check for continuity between terminals A and B.
There should be no continuity.
2. Connect a 12V battery across terminals C and D.
There should be continuity between terminals A and B.

