



Test

Fan Switch

1. Disconnect the 6P connector from the fan switch.
2. Check for continuity between the terminals of the fan switch according to the table below.

SWITCH CONNECTION

Terminal	①	②	③	④	⑤	⑥
Position						
OFF						
1	○			○		○
2	○	○				○
3	○				○	○
4	○		○			○

