


Governor Valve

Disassembly/Inspection/Reassembly

NOTE:

- Clean all parts thoroughly in solvent or carburetor cleaner, and dry with compressed air. Blow out all passages.
- Check that the governor works smoothly; replace it if it does not.
- Coat all parts with ATF before reassembly.



Spring Specifications

Unit of length mm (in.)

No.	Spring	Standard (New)				
		Wire Dia.	O.D.	Free Length	No. of Coils	
①	Governor spring A	1.4 ℓ	1.0(0.039)	18.8(0.740)	20.4(0.803)	4
		1.5 ℓ, 1.6 ℓ	1.0(0.039)	18.8(0.740)	38.1(1.500)	4
②	Governor spring B	1.4 ℓ	0.9(0.035)	11.8(0.465)	26.7(1.051)	6
		1.5 ℓ, 1.6 ℓ	0.9(0.035)	11.8(0.465)	27.8(1.094)	6