


Thermostat Replacement

NOTE : Use new gaskets and O-rings when reassembling.



Testing

Replace thermostat if it is open at room temperature.
To test a closed thermostat:

1. Suspend the thermostat in a container of water as shown.
2. Heat the water and check the temperature with a thermometer. Check the temperature at which the thermostat first opens, and at which it is fully open.

CAUTION : Do not let thermometer touch bottom of hot container.

3. Measure lift height of thermostat when fully open.

STANDARD THERMOSTAT

Lift height : 8mm (0.31in.)
Starts opening : 78°C ± 2°C (172°F ± 3°F)
Fully open : 90°C (194°F)

