


# Hood

## Replacement/Adjustment


1. Pull the windshield washer hose out of the hood.
2. Hold the hood up and remove the 2 hood mounting bolts on each side, then remove the hood.
3. To remove the hood hinges, remove the front windshield wiper and air scoop.
4. When installing the hood, don't tighten the hinge bolts until you've checked the adjustments shown below.



### HOOD EDGE CUSHION

Turn as necessary, to make the hood fit flush with the body at front and side edges.

### HOOD EDGE CUSHION




### HOOD LATCH

Adjust the hood latch to obtain the proper height at center and front edge.


### HOOD HINGE MOUNTING BOLTS

6 × 1.0 mm  
10 N·m (1.0 kg-m, 7 lb-ft)



### HOOD MOUNTING BOLTS

6 × 1.0 mm  
10 N·m (1.0 kg-m, 7 lb-ft)




### HINGE SHIM

Use shims as necessary, to make the hood fit flush with the body at the rear edge.

### HOOD

### HOOD INSULATOR

### CLIP



### HOOD HINGE

Adjust the hinges fore and aft, and right and left as necessary, to equalize the gap between the hood and the body.