









Fuel system

FUEL SYSTEM COMPONENT LOCATION - TURBO MODELS


- | | |
|------------------------|-----------------|
| 1. Fuel heater | 6. Air filter |
| 2. Fuel injector | 7. Fuel filter |
| 3. Glow plug | 8. Turbocharger |
| 4. Intercooler | |
| 5. Fuel injection pump | |

Fuel system



8RM 3854

Fuel system



FUEL SYSTEM LAYOUT

1. Fuel tank
2. Fuel pick - up pipe
3. Fuel heater
4. Fuel filter
5. Fuel injectors

6. Fuel delivery pipes
7. Fuel injection pump
8. Fuel injection pump spill return pipes
9. Injector spill return pipe.