


Electrical - Fuses

FUSES



8RM 0111D

Passenger compartment fusebox - fuse functions


FUSE No.	RATING	WIRE COLOUR	FUNCTION
1.	10 amp	G	Clock, instruments, indicators, dim dip
2.	15 amp	W/S	Fuel pump - 1.4 and 2.0
3.	15 amp	K	Central door locking
4.	10 amp	P/N	Cigar lighter
5.	10 amp	P	Dim/Dip resister
6.	30 amp	P/O	Sunroof, power hood
7.	10 amp	R/O	Number plate lamps, R.H. side, tail lamps
8.	10 amp	R/B	Cigar lighter illumination, Glovebox lamp L.H. side, rear lamps Trailer plug (where fitted)
9.	10 amp	U/R	Fog lamps
10.	10 amp	U/K	L.H. dipped beam
11.	10 amp	U/B	R.H. dipped beam
12.	15 amp	P	Clock, interior lamps, radio memory, electric aerial, CDL/Anti-theft ECU

Electrical - Fuses



13.	15 amp	G/S	Front and rear wash/wipe, CDL/Anti-theft ECU power hood
14.	10 amp	G/K	Engine management system
15.	15 amp	LG/S	Cooling fans Rear wash/wipe
16.	15 amp	G/Y	Reverse lamps, brake lamps
17.	10 amp	LG/W	Radio, CD player, panel illumination, cigar lighter
18.	10 amp	G	Door mirrors, power windows
19.	15 amp	U/P	Headlamp Dim/dip
20.	15 amp	N/R	Fog lights
21.	15 amp	U/S	Headlamp main beam - R.H.
22.	15 amp	U/G	Headlamp main beam - L.H.
23.	25 amp	N/O	Rear window demister, mirror heaters
24.	20 amp	LG/P	Heater blower motor
25.	15 amp	G/O	ABS
26.	15 amp	N/R	Rear window - L.H.
27.	15 amp	N/K	Rear window - R.H.
28.	15 amp	N/Y	Front passenger's window
29.	15 amp	S/G	Driver's window
30.	-	-	Not used

Electrical - Fuses




8RM 0104

Engine compartment fusebox 1.4, 2.0 and Diesel models

FUSE LINK NO.	RATING	WIRE COLOUR	FUNCTION
8	60 amp	-	Main Relay
9	40 amp	N/W	Master switch
10	40 amp	N	Power window relay Sunroof Central door locking
11	40 amp	N:P	Master switch
12	40 amp	N	Lighting, Cigar lighter
13	40 amp	N:K	ABS pump

FUSE NO.	RATING	WIRE COLOUR	FUNCTION
3	10 amp	N/O	Hazards
7	15 amp	P/N	Horn

RELAY	FUNCTION
A	Power wash - if fitted
B	Manifold heater - 1.4 Oxygen sensor relay - 2.0
C	Starter
D	Main
E	Cooling fan - 1.4, 2.0
F	Fuel pump - 1.4, 2.0



86M 0498 A

Rear of Engine compartment fusebox - Diesel Models

- C1** Fusebox to Main harness
- C2** Fusebox to Main harness
- C3** Fusebox to Main harness
- C4** Fusebox to Main harness
- C5** Fusebox to Main harness

- A** Not used
- C318** Fusebox to Engine harness
- C319** Fusebox to Engine harness
- C411** Fusebox to Main harness