

# Trunk Lid

## Replacement/Adjustment


1. Pull the harness and trunk lid opener cable (page 14-73) out of the trunk lid.

**NOTE:** Before pulling out the wire harness and opener cable, tie a string to the end of it so you can pull it back in when the trunk lid is reinstalled.


2. Remove the trunk lid mounting bolts, then lift off the lid.
3. Remove the torsion bar using a assembly tool.
4. Remove the rear shelf.
5. Remove the hinge bracket mounting bolts, then remove the hinges from the trunk.

### TRUNK LID EDGE CUSHION


Turn as necessary, to make the trunk lid fit flush with the body at rear and side.




### TORSION BAR ASSY TOOL 07GAZ-SE30100




⊙ = Normal tension  
● = Higher tension



### FLAT TIP SCREWDRIVER



▶ : Locations



▷ : Locations

6. Assemble in the reverse order.

**NOTE:** Before tightening the trunk lid mounting bolts, adjust the trunk lid fit and striker.