


# Rear Suspension

## Torque specifications

### CAUTION:

- Replace the self-locking nuts after removal.
- Replace the self-locking bolts after removal.


Disc Brake :



**CAUTION:** The vehicle should be on the ground before any bolts or nuts connected to rubber mounts or bushings are tightened.



**Drum Brake:**



**CAUTION:** The vehicle should be on the ground before any bolts or nuts connected to rubber mounts or bushings are tightened.