




# Rear Bumper Replacement

1. Remove the 2 bumper mounting screws on each side at the corner edge of the bumper.
2. Remove the under cover (left side), then remove the 2 lower bumper mounting nuts from under the trunk floor and center bolt.
3. Pry off the maintenance caps, then remove the 2 upper bumper mounting nuts from the trunk area.
4. Remove the bumper by sliding it to the rear.

## NOTE:

- Do not damage the threads of the bumper bolts.
- Take care not to scratch the bumper face.



5. Installation sequence is essentially the reverse order of removal.