


Front Seats

Cover Replacement


CAUTION: Wear gloves to remove and install the seat cover.

Seat Back removal:

1. Remove the seat assembly from the car.
2. Remove the reclining handle, lumbar support handle and adjuster covers.
3. Remove the clip pins and turn over the seat cover by releasing all the hooks.




4. Remove the headrest guides and seat back spring hooks, then remove the seat cover and pad, from the seat back frame.



Seat Cushion removal:

1. Remove the the seat track cover.
2. Pry off the clips and turn over the seat cover by releasing all the hooks and inside spring hooks.
3. Remove the seat cover and pad from the cushion frame.



NOTE: To prevent wrinkles when installing a seat cover, make sure the material is stretched evenly over the frame before securing all the clips.