


Shift Cable



Removal/Installation

⚠ WARNING

- Make sure jacks and safety stands are placed properly and hoist brackets are attached to correct positions on the engine.
 - Apply parking brake and block rear wheels, so car will not roll off stands and fall on you while working under it.
1. Remove the header pipe, header pipe bracket, torque converter cover and cable holder.
 2. Remove the shift cable by removing the cotter pin, control pin and control lever roller from the control lever.
 3. Remove the bolts, then remove the cable bracket.

4. Remove the front console.
5. Remove the lock pin from the cable adjuster, then remove the shift cable.

CAUTION: Take care not to bend the cable when removing it.

6. Install the shift cable in the reverse order of removal. **NOTE:** On reassembly, check the cable adjustment (page 9-42).

