

CAPACITIES

Fuel tank	55 litres
Engine oil refill and filter change	4.5 litres
Manual gearbox refill	2.0 litres
Power steering reservoir	1.2 litres
Cooling system refill	8.0 litres
Washer reservoir:	
R.H.D. models	3.1 litres
L.H.D. models	3.7 litres

FLUIDS

Fuel Diesel fuel oil, distillate, diesel fuel, automotive gas oil or Derv fuel to British Standard 2869, Class A1 or equivalent.

Brake Fluid

Use only AP New Premium Super DOT 4 brake fluid or Castrol Girling Universal DOT 4 brake/clutch fluid. DO NOT use any other type of fluid.

If this is not available, use an ethylene glycol based anti-freeze, containing no methanol with non-phosphate corrosion inhibitors suitable for use in mixed metal engines to ensure the protection of the cooling system against frost and damage.

Anti-freeze solutions

The overall anti-freeze concentration should not fall, below 50% to ensure that the anti-corrosion properties of the coolant are maintained.

CAUTION: No other anti-freeze should be used with UNIPART Superplus Anti-freeze.

Anti-freeze concentrations greater than 60% are not recommended as cooling efficiency will be impaired.

The cooling system should be drained, flushed and refilled with the correct amount of anti-freeze solution at the intervals given on the Maintenance Check Sheet.

Use UNIPART Superplus Anti-freeze and Summer Coolant

After filling with anti-freeze solution, attach a warning label to a prominent position on the vehicle stating the type of anti-freeze contained in the cooling system to ensure that the correct type is used for topping-up.

The recommended quantities of anti-freeze for different degrees of frost protection are:

Solution	Amount of anti-freeze	Commences freezing		Frozen solid	
		°C	°F	°C	°F
50%	Litres	-36	-33	-48	-53
All Models	4.0	-36	-33	-48	-53