


Power Windows


Motor Replacement




1. Remove the door trim panel.
2. Disconnect the 4-P connector from the door wire harness.
3. Remove the regulator assembly. (See section 14)
4. Remove the 4 rivets from the regulator panel plate, with a drill diameter 4.2 mm.



5. Pull out the rivets from the motor.



6. Fix the motor with 4 screws and 4 nuts on the regulator panel plate.



7. Add a drop of "LOCTITE" glue on the nuts to secure.
8. Assemble the regulator assembly in the reverse order of disassembly. (See section 14)
9. After installation, check the smooth movement of door glass.